

PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / ARTICLE NO. / ARTICULO NO. : P344100 / 110

DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR
MIRROR / MIROIR / ESPEJO



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*



(A)

x1 Dresser
x1 Commode
x1 Tocador




(B)

x1 Mirror Support ★
x1 Supporte de miroir
x1 Soporte del espejo




(C)

x4 Leg ★
x4 Jambes
x4 Piernas



(D)

x1 Support Leg ★
x1 Pied
x1 Pata De Soporte



(E)

x8 Allen bolt $\phi 1/4$ "x35mm ★
x8 Vis à tête creuse hexagonale $\phi 1/4$ "x35mm
x8 Perno Allen $\phi 1/4$ "x35mm



(F)

x8 Lock washer $\phi 1/4$ " ★
x8 Rondelle de blocage $\phi 1/4$ "
x8 Arandela de Seguridad $\phi 1/4$ "



(G)

x8 Flat Washer $\phi 1/4$ "x19x1.5mm ★
x8 Rondelle plate $\phi 1/4$ "x19x1.5mm
x8 Arandela plana $\phi 1/4$ "x19x1.5mm



(H)

x1 Allen Key 5mm ★
x1 Clé hexagonale 5mm
x1 Llave Allen 5mm



(I)

x1 Furniture Tipping Restraint ★
x1 Systeme antibasculement
x1 Control para evitar vulcos

★ Replaceable Part

ASSEMBLY INSTRUCTIONS / NO TICE DE MONTAGE / INSTRUCCIONES DE MONTAJE

ITEM NO. / ARTICLE NO. / ARTICULO NO. : P344100 / 110

DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR
MIRROR / MIROIR / ESPEJO

⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*




2

1

A

C

D



* Replaceable Part

ASSEMBLY INSTRUCTIONS / NO TICE DE MONTAGE / INSTRUCCIONES DE MONTAJE

ITEM NO. / ARTICLE NO. / ARTICULO NO. : P344100 / 110

DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR
MIRROR / MIROIR / ESPEJO

⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


*This is a permanent label.
Do not remove!*



3



* Replaceable Part



REPLACEABLE PART / PARTIE REMPLAÇABLE / PARTE REEMPLAZABLE

ITEM NO. / ARTICLE NO. / ARTICULONO. : P344100 / 110

DESCRIPTION / LA DESCRIPCION / DESCRIPCIÓN : DRESSER / COMMODE / TOCADOR
MIRROR / MIROIR / ESPEJO


WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*




x6 RP344-PULL - Knob with Screw *
Poignée et vis
Tirador y Tornillo



x6 COMGLIDE-14-45 - Glide 14in 45mm *
Glissière
Carril de deslizamiento




x1 RP344100-CELEG - Support Leg *
Support central
Soporte para la pata central




x4 RP344100-LEG - Leg *
Jambes
Piernas



x1 RP344110-MISU - Mirror Support *
Supporte de miroir
Soporte del espejo




x1 RC-ANTI-TIP - Furniture Tipping Restraint *
Système antibasculement
Control para evitar vuelcos



x2 RP344100-FELT - Removeable Felt *
Feutre
Fieltro




x1 RP344110-HWKIT - Hardware Kit *
Liste des pièces de quincaillerie
Lista del kit de materiales



x1 RC-FG-WHITE - White leveler *
Patin réglable
Nivelador



x4 RC-WH-NAIL - Plastic nail
Clou en plastique
Clavo de plástico



* Replaceable Part

Protect Your Wood or Laminate Flooring

*This statement applies to any floor without carpet.

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floors without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.