

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

706228
LIFT TOP COFFEE TABLE

ITEM: 706228



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES





PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	J	UPPER FRONT AND BACK PANEL		2 PCS
B	RIGHT SIDE PANEL		1 PC	K	TOP PANEL		1 PC
C	MIDDLE DIVIDER PANEL		1 PC	L	BACK PANEL		1 PC
D	UPPER LEFT DIVIDER PANEL		1 PC	M	LEFT DRAWER FRONT PANEL		1 PC
E	UPPER RIGHT DIVIDER PANEL		1 PC	N	DRAWER BACK PANEL		2 PCS
F	LOWER FRONT TOP BAR		2 PCS	O	DRAWER LEFT SIDE PANEL		2 PCS
G	BOTTOM PANEL		1 PC	P	DRAWER RIGHT SIDE PANEL		2 PCS
H	UPPER DECORATIVE STRIP		1 PC	Q	DRAWER BOTTOM PANEL		2 PCS
I	MIDDLE PANEL		1 PC	R	RIGHT DRAWER FRONT PANEL		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		2 PCS	10	SPRING BLK		2 PCS
2	WOODEN DOWEL Ø8 x 30mm		70 PCS	11	BOLT Ø5.8x16mm BLK		12 PCS
3	CAM BOLT Ø7 x 35.5mm SR		38 PCS	12	BOLT M6x19mm BLK		4 PCS
4	CAM LOCK Ø15 x 12mm SR		38 PCS	13	ALLEN WRENCH 4mm SR		1 PC
5	LONG SCREW Ø 4.5x42mm SR		8 PCS	14	WHEEL		5 PCS
6	SCREW Ø 4.3x35mm SR		8 PCS	15	RAIL SCREW Ø 3x15mm SR		20 PCS
7	GLIDES L = 350mm BLK		2 PCS	16	STICKER Ø20mm		7 PCS
8	GLIDES SCREW Ø 3x10mm BLK		24 PCS	17	BOLT M6x28mm BLK		4 PCS
9	LIFTER BLK		1 SET				

Z7, Z9, Z14, Z15 not included in blister packaging.




NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.





ITEM: 706228

COASTER
FINE FURNITURE


STEP 1



STEP 2



INCORRECT
CORRECT








Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: 706228

COASTER
FINE FURNITURE

STEP 3







INCORRECT
CORRECT





Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 4




the reverse side




ITEM: 706228

COASTER
FINE FURNITURE

STEP 5




STEP 6





ITEM: 706228

COASTER
FINE FURNITURE

STEP 7




STEP 8





ITEM: 706228

STEP 9




STEP 10





ITEM: 706228

COASTER
FINE FURNITURE

STEP 11





STEP 12




ITEM: 706228

COASTER
FINE FURNITURE

STEP 13



STEP 14







ITEM: 706228




COASTER[®]

FINE FURNITURE

STEP 15







STEP 16





ITEM: 706228

COASTER
FINE FURNITURE

STEP 17





STEP 18





ITEM: 706228

STEP 19




STEP 20




ITEM: 706228

COASTER
FINE FURNITURE


STEP 21-1




STEP 21-2




STEP 21-3



STEP 21-4




STEP 21-5




ITEM: 706228



STEP 22



STEP 23

COMPLETE





Note : Dimension tolerance $\pm 5\%$