


UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 30740

Carefully unpack all Assembly Parts from the carton.

1. Place the lamp base on a level surface.
2. Use a Philips screwdriver to loosen **Screw C** on top of the **Plate** per the diagram below.
3. Looking at the bracket on the **Fabric Shade**, place **Hole A** and **Hole B** over **Screw A** and **Screw B**. Turn clockwise to lock into place. Tighten **Screw C** to secure.
4. Install the correct bulb referring to fixture markings and/or labels for maximum wattage. (Bulb not included)
5. Place the **Glass Shade** over the bulb and turn clockwise by hand until secured into place.



30740