

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710567 <u>End Table</u>

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP 1PC

B LEG 4PCS

C BOTTOM SHELF 1PC


HARDWARE IDENTIFICATION

| 1 | BOLT (Ø1/4" x 2-1/4" - BLK) | 12PCS |
|---|-----------------------------------|-------|
| 2 | LOCK WASHER (1/4 x 16mm - BLK) | 12PCS |
| 3 | FLAT WASHER (Ø1/4" - BLK) | 12PCS |
| 4 | ALLEN WRENCH (4mm - BLK) | 1PC |


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

COASTER

STEP 3




STEP 4




ASSEMBLY INSTRUCTIONS

COASTER

STEP 5



STEP 6 COMPLETE




PAGE 5 OF 5

COASTERFURNITURE.COM



Inner Size of Drawer: 10.50"W x 13.50"D X 2.75"H X 0.25"T



Note: Dimension tolerance ± 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710568 <u>Coffee Table</u>

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP 1PC

B LEG 4PCS

C BOTTOM SHELF 1PC

HARDWARE IDENTIFICATION


| 1 | BOLT (Ø1/4" x 2-1/4" - BLK) | 8PCS |
|---|-----------------------------------|------|
| 2 | LOCK WASHER (1/4 x 16mm - BLK) | 8PCS |
| 3 | FLAT WASHER (Ø1/4" - BLK) | 8PCS |
| 4 | ALLEN WRENCH (4mm - BLK) | 1PC |

ASSEMBLY INSTRUCTIONS


STEP 1



COASTERFURNITURE.COM



STEP 2




PAGE 3 OF 4


ASSEMBLY INSTRUCTIONS

COASTER'

STEP 3




STEP 4 COMPLETE



COASTERFURNITURE.COM

PAGE 4 OF 4





Note: Dimension tolerance ± 5%