

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 722208 COFFEE TABLE

REVISION 0: 12/29/2020

PAGE 1 OF 6

COASTERFURNITURE.COM




#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 40 MINUTES

#### PARTS IDENTIFICATION

А	TOP		1PC
В	UPPER LEG FRAME		1PC
С	LOWER LEG FRAME		1PC
D	LEG	0	4PCS
E	SHELF		1PC
F	CASTER		4PCS
	PAGE 2 OF 6	COASTERFU	RNITURE.COM




### HARDWARE IDENTIFICATION

1	BOLT (1/4" x 12mm BLK)	9PCS
2	LONG BOLT (ø1/4" x 127mm BLK)	4PCS
3	CAP (20 x 40mm BLK)	4PCS
4	L BRACKET (27 x 27mm)	4PCS
5	WASHER	4PCS
6	ALLEN KEY (4mm)	1PC
7	HEXAGONAL KEY	1PC





STEP 1

Do not tighten until each step is completed or instructed.




#### STEP 2










## STEP 4 COMPLETE








Product Size: DIA 889 X 464 H (MM)

**Product Size : DIA 35" X 18.25"** 



Note: Dimension tolerance ±5%