

Wireless Stereo Headset Casque stéréo sans fil

Reference Guide Guide de référence Guía de referencia

https://rd1.sony.net/help/mdr/wic100/h_zz/



WI-C100

Model, Modèle, Modelo: YY2957

5-036-679-11(1)



* 5 0 3 6 6 7 9 1 1 * (1)

©2022 Sony Corporation
Printed in Vietnam
Imprimé au Vietnam
<https://www.sony.net/>

English

Wireless Stereo Headset

Model: YY2957

FOR UNITED STATES CUSTOMERS. NOT APPLICABLE IN CANADA,
INCLUDING IN THE PROVINCE OF QUEBEC.
POUR LES CONSOMMATEURS AUX ÉTATS-UNIS. NON APPLICABLE AU
CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

Do not install the product in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat, such as sunshine, fire or the like for a long time.

Do not dismantle, open or shred secondary cells or batteries.

Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.

In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Secondary cells and batteries need to be charged before use. Always refer to the manufacturer's instructions or product manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.

Dispose of properly.

RECYCLING RECHARGEABLE BATTERIES

Rechargeable batteries are recyclable.

You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you. For more information regarding recycling of rechargeable batteries, visit <http://www.sony.com/electronics/eco/environmental-management>

Caution: Do not handle damaged or leaking rechargeable batteries.

FOR UNITED STATES CUSTOMERS. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC.

POUR LES CONSOMMATEURS AUX ÉTATS-UNIS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this unit.

If you have any questions about this product:

Visit: <https://www.sony.com/electronics/support>

Contact: Sony Customer Information Service Center at 1-800-222-7669

Write: Sony Customer Information Service Center 12451 Gateway Blvd.,
Fort Myers, FL 33913

Supplier's Declaration of Conformity

Trade Name: SONY

Model: YY2957

Responsible Party: Sony Electronics Inc.

Address: 16535 Via Esprillo, San Diego, CA 92127 U.S.A.

Telephone Number: 858-942-2230

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This unit has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this unit does cause harmful interference to radio or television reception, which can be determined by turning the unit off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the unit and receiver.
- Connect the unit into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This unit must not be co-located or operated in conjunction with any other antenna or transmitter.

This unit complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This unit has very low levels of RF energy that is deemed to comply without testing of specific absorption rate (SAR).

For customers in Canada

This unit contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This unit may not cause interference; and
- (2) This unit must accept any interference, including interference that may cause undesired operation of the unit.

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research.

The unit has been tested and found to comply with ISED radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the ISED radio frequency (RF) Exposure rules.

High volume may adversely affect your hearing.

Do not use the unit while walking, driving, or cycling. Doing so may cause traffic accidents.

Do not use in hazardous areas unless the surrounding sound can be heard.

If water or foreign matter enters the unit, it may result in fire or electric shock. If water or foreign matter enters the unit, stop use immediately and consult your nearest Sony dealer. In particular, be careful in the following cases.

- When using the unit near a sink or liquid container

Be careful that the unit does not fall into a sink or container filled with water.

- When using the unit in the rain or snow, or in humid locations

For details on the effects of contact with the human body from the mobile phone or other wireless devices connected to the unit, refer to the instruction manual of the wireless device.

If the earbud tips are not securely attached, they may fall off and remain inside the ear during use. Make sure that the earbud tips are securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter on the unit or charging cable, and cause abnormal heat generation or malfunction.

This product (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

There is a danger that small parts may be swallowed. After use, store in a location out of reach of small children.

Note about static electricity

If you use the unit when the air is dry, you may experience discomfort due to static electricity accumulated on your body. This is not a malfunction of the unit. You can reduce the effect by wearing clothes made of natural materials that do not easily generate static electricity.

IMPORTANT

The factory default setting of the voice guidance for this unit is English. The voice guidance can be heard from the unit in the following situations:

- When powering on: "Power on"
- When powering off: "Power off"

- When the remaining battery level is low and recharge is recommended: "Low battery, please recharge headset"
- When automatically turning off due to low battery: "Please recharge headset. Power off"

- When checking the remaining battery level: "Battery fully charged" / "Battery about 70%" / "Battery about 50%"

- When entering pairing mode: "Bluetooth pairing"

- When establishing a Bluetooth connection: "Bluetooth connected"

- When disconnecting a Bluetooth connection: "Bluetooth disconnected"

Precautions

The two-dimensional code or the URL on the cover will help you access the help guide that describes useful notes or procedures in details.

On water resistant of the unit

- Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
- Note the following cautions carefully and use the unit correctly. (Make sure that the USB Type-C® port cover is closed securely when you use the unit.)

To maintain water resistant performance

Carefully note the precautions below to ensure proper use of the unit.

- Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover or it is not completely closed, the water resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

• Do not splash water forcibly into the sound output holes.

• Do not drop the unit into water, and do not use underwater.

• Do not allow the unit to remain wet in a cold environment, as the water may freeze. To prevent malfunction, make sure to wipe off any water after use.

• Do not place the unit in water or use it in a humid place such as a bathroom.

• Do not drop the unit or expose it to mechanical shock. Doing so may deform or damage the unit, resulting in deterioration of water resistance performance.

On BLUETOOTH® communications

Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident:

- in hospitals, near priority seating in trains, locations where inflammable gas is present, near automatic doors, or near fire alarms.

IMPORTANT

The factory default setting of the voice guidance for this unit is English. The voice guidance can be heard from the unit in the following situations:

- When powering on: "Power on"
- When powering off: "Power off"

- When the remaining battery level is low and recharge is recommended: "Low battery, please recharge headset"

- When automatically turning off due to low battery: "Please recharge headset. Power off"

- When checking the remaining battery level: "Battery fully charged" / "Battery about 70%" / "Battery about 50%"

- When entering pairing mode: "Bluetooth pairing"


- When establishing a Bluetooth connection: "Bluetooth connected"

- When disconnecting a Bluetooth connection: "Bluetooth disconnected"

On charging the unit

- Make sure to close the USB Type-C port cover securely after charging.

Perspiration or water may cause damage.



Notes on wearing the unit

- After use, remove the headphones slowly.
- Because the earbud tips achieve a tight seal in the ears, forcibly pressing them in or quickly pulling them out can result in eardrum damage. When wearing the earbud tips, the speaker diaphragm may produce a click sound. This is not a malfunction.

Other notes

- If you experience discomfort while using the unit, stop using it immediately.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Licenses

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license.

<https://rd1.sony.net/help/mdr/sl/22/>

Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Specifications

Headset

Power source:

DC 3.7 V: Built-in lithium-ion rechargeable battery
DC 5 V: When charged using USB

Operating temperature:

0 °C to 40 °C (32 °F to 104 °F)

Rated power consumption:

0.4 W

Mass:

Approx. 20 g (0.71 oz)

Included items:

Wireless Stereo Headset (1)
Hybrid silicone rubber earbud tips (S5 (1 line) (2), M (3 lines) (attached to the unit at the factory) (2), LL (5 lines) (2))

Communication specification

Communication system:

Bluetooth Specification version 5.0

Output:

Bluetooth Specification Power Class 2

Frequency band:

2.4 GHz band (2.4000 GHz - 2.4835 GHz)

Design and specifications are subject to change without notice.

System requirements for battery charge using USB

USB AC adaptor

A commercially available USB AC adaptor capable of supplying an output current of 0.5 A (500 mA) or more</p

Précautions

Le code à deux dimensions ou l'URL figurant sur le couvercle vous permettent d'accéder au guide d'aide qui contient des remarques utiles et décrit les procédures en détail.

À propos de la résistance à l'eau du dispositif

- À moins que le dispositif ne soit utilisé convenablement, de l'eau peut pénétrer dans le dispositif et provoquer un incendie, une électrocution ou des dysfonctionnements.
Lisez attentivement les mesures de précaution suivantes, puis utilisez le dispositif convenablement.
(Veuillez à ce que le cache du port USB Type-C® soit bien fermé lors de l'utilisation du dispositif.)

Pour préserver les performances de résistance à l'eau

Lisez attentivement les mesures de précaution ci-dessous afin de garantir une bonne utilisation du dispositif.


- Veillez à ce que le cache du port USB Type-C soit bien fermé lors de l'utilisation du dispositif. En présence de corps étrangers sur le cache ou si celui-ci n'est pas complètement fermé, les performances de résistance à l'eau peuvent ne pas être préservées. De l'eau peut pénétrer à l'intérieur du dispositif et provoquer un dysfonctionnement de celui-ci.
- Ne projetez pas d'eau avec vigueur dans les orifices de sortie audio.
- Ne laissez pas tomber le dispositif dans l'eau et ne l'utilisez pas sous l'eau.
- Ne laissez pas le dispositif humide dans un environnement froid, car l'eau peut geler. Pour éviter tout dysfonctionnement, veillez à essuyer toute l'eau après utilisation.
- Ne placez pas le dispositif dans l'eau et ne l'utilisez pas dans un endroit humide comme une salle de bain.
- Ne laissez pas tomber le dispositif et ne l'exposez pas à des chocs mécaniques. Cela pourrait déformer ou endommager le dispositif, entraînant ainsi une dégradation de ses performances en matière de résistance à l'eau.

Sur les communications BLUETOOTH®

- Les micro-ondes émises par tout appareil Bluetooth peuvent affecter le fonctionnement des dispositifs médicaux électroniques. Éteignez le dispositif et tout autre appareil Bluetooth dans les lieux suivants afin d'éviter tout accident :
 - dans les hôpitaux, à proximité des sièges prioritaires de train, des endroits accueillant tout gaz inflammable, ainsi que près des alarmes incendie ou des portes automatiques.

Chargement du dispositif

- Veillez à bien fermer le cache du port USB Type-C après toute opération de charge. La transpiration ou l'eau peuvent être source de dommages.



Remarques sur le port du dispositif

- Après utilisation, retirez le casque d'écoute lentement.
- Les embouts d'oreillettes permettant d'établir un joint étanche sur les oreilles, le fait de les presser avec vigueur ou de les retirer rapidement peut entraîner des lésions des tympans.
Lors du port des embouts d'oreillettes, le diaphragme du haut-parleur peut produire un cliquetis. Il ne s'agit pas d'un dysfonctionnement.

Autres remarques

- Si vous ressentez une gêne lors de l'utilisation du dispositif, arrêtez de l'utiliser immédiatement.
- Pour obtenir des réponses à toutes questions ou des solutions pour tous problèmes concernant le dispositif, qui ne sont pas abordés dans ce manuel, veuillez consulter votre revendeur Sony le plus proche.

- Ce produit contient des logiciels utilisés par Sony dans le cadre d'un contrat de licence conclu avec le propriétaire de ses droits d'auteur. Nous sommes tenus d'annoncer le contenu du contrat aux clients, conformément à l'accord passé avec le propriétaire des droits d'auteur du logiciel. Veuillez cliquer sur le lien et lire le contenu de la licence.
<https://rd1.sony.net/help/mdr/sl/22/>
- Les services proposés par des tiers peuvent être modifiés, suspendus ou clôturés sans avis préalable. Sony n'assume aucune responsabilité dans ce genre de situation.

Spécifications

Casque

NOT FOR CANADIAN CUSTOMERS. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC.

NE S'ADRESSE PAS AUX CONSOMMATEURS CANADIENS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

NO APLICA PARA EL CLIENTE CANADIENSE. NO APlicable EN CANADÁ, INCLUIDA LA PROVINCIA DE QUÉBEC.

Auriculares estéreo inalámbricos

Modelo: YY2957

POR FAVOR LEA DETALLADAMENTE ESTE MANUAL DE INSTRUCCIONES ANTES DE CONECTAR Y OPERAR ESTE EQUIPO.

RECUEDE QUE UN MAL USO DE SU APARATO PODRÁ ANULAR LA GARANTÍA.

Spécifications de communication

Système de communication :

Spécification Bluetooth version 5.0

Sortie :

Spécification Bluetooth classe de puissance 2

Gamme de fréquences :

Bande de 2,4 GHz (2,4000 GHz - 2,4835 GHz)

La conception et les spécifications peuvent être modifiées sans préavis.

Configuration système pour la charge de la batterie par USB

Adaptateur secteur USB

Adaptateur secteur USB disponible dans le commerce capable de fournir un courant de sortie de 0,5 A (500 mA) minimum

- N'utilisez pas d'adaptateur USB qui dépasse la puissance maximale de 13 W (5 V, 2,6 A).

Câble USB

Câble USB Type-C disponible dans le commerce (conforme aux normes USB)

Modèles compatibles avec iPhone/ iPod

iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2ème génération), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone 5s, iPod touch (7ème génération), iPod touch (6ème génération)
(À compter de janvier 2022)

Marques

- Apple, iPhone, iPod et iPod touch sont des marques commerciales d'Apple Inc., déposées aux États-Unis et dans d'autres pays.
- La marque et les logos Bluetooth® sont des marques commerciales déposées appartenant à Bluetooth SIG, Inc. et toute utilisation de ces marques par Sony Group Corporation et ses filiales est sous licence.
- USB Type-C® et USB-C® sont des marques commerciales déposées d'USB Implementers Forum.
- Toutes les autres marques et marques déposées sont des marques ou des marques déposées de leurs détenteurs respectifs. Les symboles™ et ® n'apparaissent pas dans ce manuel.

Licences

- L'utilisation du badge Made for Apple signifie qu'un accessoire a été conçu pour être raccordé spécifiquement au produit ou aux produits Apple identifiés dans le badge, et a été certifié par le constructeur pour satisfaire les normes de performance d'Apple. Apple n'est pas responsable du fonctionnement de cet appareil ni de sa conformité avec les consignes et normes de sécurité.
- Ce produit contient des logiciels utilisés par Sony dans le cadre d'un contrat de licence conclu avec le propriétaire de ses droits d'auteur. Nous sommes tenus d'annoncer le contenu du contrat aux clients, conformément à l'accord passé avec le propriétaire des droits d'auteur du logiciel. Veuillez cliquer sur le lien et lire le contenu de la licence.
<https://rd1.sony.net/help/mdr/sl/22/>
- Les services proposés par des tiers peuvent être modifiés, suspendus ou clôturés sans avis préalable. Sony n'assume aucune responsabilité dans ce genre de situation.

Español

NOT FOR CANADIAN CUSTOMERS. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC.

NE S'ADRESSE PAS AUX CONSOMMATEURS CANADIENS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

NO APLICA PARA EL CLIENTE CANADIENSE. NO APlicable EN CANADÁ, INCLUIDA LA PROVINCIA DE QUÉBEC.

Auriculares estéreo inalámbricos

Modelo: YY2957

POR FAVOR LEA DETALLADAMENTE ESTE MANUAL DE INSTRUCCIONES ANTES DE CONECTAR Y OPERAR ESTE EQUIPO.

RECUEDE QUE UN MAL USO DE SU APARATO PODRÁ ANULAR LA GARANTÍA.

AVISO IMPORTANTE PARA MÉXICO

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Para consultar la información relacionada al número del certificado, refiérase a la etiqueta del empaque y/o del producto.

Nota: Información de dispositivo(s) para funcionalidades inalámbricas:
Modelo: AB1561M, Marca: Airoha

No instale el producto en un espacio reducido, como una estantería o un armario empotrado.

No exponga las baterías (paquete de baterías o baterías instaladas) a un calor excesivo, como la luz del sol, el fuego o similares durante un periodo prolongado.

No desmonte, abra ni corte las celdas secundarias ni las baterías.

No exponga las baterías o las celdas al calor o el fuego. Evite guardarlas en contacto directo con la luz del sol.

En caso de fuga de una celda, no deje que el líquido entre en contacto con la piel o los ojos. Si se ha producido contacto, lave la zona afectada con abundante agua y busque asistencia médica.

Hay que cargar las celdas secundarias y las baterías antes de utilizarlas. Consulte siempre las instrucciones del fabricante o el manual del producto para conocer las instrucciones de carga adecuadas.

Después de períodos prolongados de almacenamiento, es posible que se deba cargar y descargar las celdas o las baterías varias veces a fin de alcanzar su rendimiento máximo.

Deséchelas correctamente.

El volumen alto puede afectar negativamente a la audición.

No utilice la unidad mientras camina, conduce o monta en bicicleta. Hacerlo puede causar accidentes de tránsito.

No la utilice en zonas peligrosas a menos que pueda oír los sonidos que lo rodean.

La unidad puede incendiarse o producir una descarga eléctrica si entran agua u objetos extraños en ella. Si entran agua o un objeto extraño en la unidad, deje de utilizarla inmediatamente y consulte con su distribuidor de Sony más cercano. En especial, tenga cuidado en los siguientes casos.

- Cuando utilice la unidad cerca de un fregadero o recipiente lleno de agua. Tenga cuidado de que la unidad no caiga en un fregadero ni contenedor lleno de agua.

- Cuando utilice la unidad en la lluvia, en la nieve o en lugares húmedos.

Precauciones

El código bidimensional o la URL de la portada permiten acceder a la guía de ayuda, que presenta notas útiles o procedimientos de forma detallada.

Acerca de la capacidad resistente al agua de la unidad

- Si la unidad no se utiliza correctamente, es posible que entre agua y que se produzca un incendio, una electrocución o un error de funcionamiento.
- Preste mucha atención a las siguientes precauciones y utilice la unidad correctamente.
(Asegúrese de que la tapa del puerto USB Type-C® esté correctamente cerrada cuando utilice la unidad.)

Para preservar el rendimiento resistente al agua

Preste mucha atención a las siguientes precauciones para garantizar el uso correcto de la unidad.

- Asegúrese de que la tapa del puerto USB Type-C® esté correctamente cerrada cuando utilice la unidad. Si la tapa tiene materias extrañas o no está totalmente cerrada, no se puede preservar el rendimiento resistente al agua. El agua puede entrar y hacer que la unidad sufra errores de funcionamiento.

- No salpique agua a propósito en los orificios de salida del sonido.

- No deje caer la unidad al agua ni la utilice sumergida.

- No deje que la unidad permanezca húmeda en un entorno frío, ya que el agua podría congelarse. Para evitar los errores de funcionamiento, asegúrese de limpiar el agua después del uso.

- No coloque la unidad en el agua ni la utilice en lugares húmedos, como el baño.

- No deje caer la unidad ni la exponga a impactos mecánicos. De hacerlo, la unidad podría dañarse o deformarse, lo que produciría el deterioro del rendimiento de resistencia al agua.

- Cuando utilice la unidad en la lluvia, en la nieve o en lugares húmedos.

Sobre las comunicaciones BLUETOOTH®

- Las microondas que se emiten desde un dispositivo Bluetooth pueden afectar al funcionamiento de dispositivos médicos electrónicos. Apague esta unidad y otros dispositivos Bluetooth si se encuentra en las siguientes ubicaciones, ya que puede causar un accidente:
 - en hospitales, cerca de asientos prioritarios en los trenes, en ubicaciones donde haya gas inflamable, cerca de puertas automáticas o cerca de alarmas de incendios.

Adaptador de ca USB

Un adaptador USB de ca disponible en el mercado capaz de suministrar una salida de corriente de 0,5 A (500 mA) o más

- No utilice un adaptador USB que supere los 13 W (5 V, 2,6 A) de salida máxima.

Cable USB

Cable USB Type-C disponible en el mercado (cumple los estándares de USB)

Modelos de iPhone/iPod compatibles

iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2.ª generación), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone 5s, iPod touch (7.ª generación), iPod touch (6.ª generación)
(A fecha de enero de 2022)

Conçu pour

iPhone | iPod

</