

E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS

MODEL #

CM6229


Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED



Socket Wrench (Included)





2 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 20-11-17






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.

Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND **CARE ADVICE**




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY **RESULT IN INJURY AND/OR PROPERTY DAMAGE.**




Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.






Save the instructions and store any supplied tools for later maintenance.

After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS							
(#1) 1pc	(#2) 1pc	(#3) 1pc	(#4) 1pc	(#5) 1pc			
		(
Left Chair Back Cushion	Left Chair Seat	Left Arm Rest	Console Back Cusł	nion Console Seat			
(#6) 2pcs	(#7) 2pcs	(##	3) 1pc	(#9) 1pc			
B							
Armless Back Cushion	Armless Chair Seat	Left Corne	er Back Cushion	Right Corner Back Cushion			
(#10) 1pc	(#11) 1pc	(#1)) 1pc	(#13) 1pc			
Corner Seat	Right Chaise Back Cushior	n Right	Chaise Seat	Right Arm Rest			
HARDWARE							
(#A) 4pcs	#B 4pcs	(#9) 4pcs	(#D) 4pcs			
5/16"	5/16"		O 5/16"	5/16"			
Threaded Rods	Hexagon Nuts	Loc	k Washers	Flat Washers			
(#E) 1pc	(#F) 4pcs	(#0	G) 4pcs				
EZ)				
Wrench	Plug-in Power Supply	Thre	eaded Rods				

Exploded View




CM6229 is packed in 6 cases

Carton	Disignation		Part	Hardware
CM6229-LCH	Left Chair Back Cushion	#1		#F x 1pc #G x 2pcs
	Left Chair Seat	#2		
	Left Arm Rest	#3	(
CM6229-CN	Console Back Cushion	#4		
	Console Seat	#5		
CM6229-AC	Armless Back Cushion	#6	× 2	#F x 2pcs
	Armless Chair Seat	#7	× 2	
CM6229-CNR	Left Corner Back Cushion	#8		#A x 4pcs #B x 4pcs #B x 4pcs #C x 4pcs #D x 4pcs #E x 1pc
	Right Corner Back Cushion	#9		
	Corner Seat	#10		
CM6229-RCE	Right Chaise Back Cushion	#11		#F x 1pc #G x 2pcs
	Right Chaise Seat	#12		
	Right Arm Rest	#13		


1 Part **#3** ×1pc Hardware **#**G ×2pcs

Attach threaded rods (#G) to the left arm rest (#3).





Insert left arm rest (#3) to the left chair seat (#2).




3 Part (1) x1pc

Align and attach the metal brackets of the backrest (#1) to the metal brackets of the seat (#2).


4


Part # x1pc Part # x1pc




Align and attach the metal brackets of the console back cushion (#4) to the metal brackets of the console seat (#5).









7 Part #10 ×1pc Hardware #B ×4pcs Hardware #C ×4pcs Hardware #D ×4pcs Hardware #E ×1pc Align back cushions (#8,9) to the corner seat (#10), then secure by using nuts (#B) with washers (#C,D).




8 Part #13×1pc Hardware #G x2pcs












11






13



14



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!


Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!


To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

15


If another console was purchased.




16



17



18



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.