

OMA

► ARROWS INDICATE WHERE COMPONENTS CONNECT

	EXTENDED SOFA 101.5"W × 36.5"D × 32.5"H Fabric 30151-S3 Leather 37151-S3		LEFT-HAND LOVESEAT 65"W × 36.5"D × 32.5"H Fabric 30151-07 Leather 37151-07		RIGHT-HAND BACKLESS CHAISE 59"W × 36.5"D × 32.5"H Fabric 30151-36 Leather 37151-36
	SOFA 89.5"W × 36.5"D × 32.5"H Fabric 30151-01 Leather 37151-01		RIGHT-HAND LOVESEAT 65"W × 36.5"D × 32.5"H Fabric 30151-08 Leather 37151-08		CORNER 36.5"W × 36.5"D × 32.5"H Fabric 30151-09 Leather 37151-09
	LEFT-HAND SOFA SPLIT 101.5"W × 36.5"D × 32.5"H Fabric 30151-39 Leather 37151-39		LEFT-HAND CORNER LOVESEAT 65.5"W × 36.5"D × 32.5"H Fabric 30151-37 Leather 37151-37		ARMLESS CHAIR 30"W × 36.5"D × 32.5"H Fabric 30151-10 Leather 37151-10
	RIGHT-HAND SOFA SPLIT 101.5"W × 36.5"D × 32.5"H Fabric 30151-40 Leather 37151-40		RIGHT-HAND CORNER LOVESEAT 65.5"W × 36.5"D × 32.5"H Fabric 30151-38 Leather 37151-38		ARMLESS LOVESEAT 59"W × 36.5"D × 32.5"H Fabric 30151-14 Leather 37151-14
	LEFT-HAND SOFA 94.5"W × 36.5"D × 32.5"H Fabric 30151-86 Leather 37151-86		LEFT-HAND CHAISE 36.5"W × 59.25"D × 32.5"H Fabric 30151-16 Leather 37151-16		RECTANGULAR OTTOMAN 30"W × 36.5"D × 18.5"H Fabric 30151-64 Leather 37151-64
	RIGHT-HAND SOFA 94.5"W × 36.5"D × 32.5"H Fabric 30151-87 Leather 37151-87		RIGHT-HAND CHAISE 36.5"W × 59.25"D × 32.5"H Fabric 30151-15 Leather 37151-15		SQUARE OTTOMAN 36.5"W × 36.5"D × 18.5"H Fabric 30151-74 Leather 37151-74
	LOVESEAT 72.5"W × 36.5"D × 32.5"H Fabric 30151-03 Leather 37151-03		LEFT-HAND BACKLESS CHAISE 59"W × 36.5"D × 32.5"H Fabric 30151-35 Leather 37151-35		


LEG OPTIONS



OTHER DETAILS

Seat Fill:	Memory Foam
Back Fill:	Feather + Fiber
Suspension:	Italian Webbing

POPULAR CONFIGURATIONS



OTHER DIMENSIONS

Seat Depth:	22"
Seat Height:	18.5"
Arm Width:	7.25"
Arm Height:	26.13"
Leg Height:	7.4"