


Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. Customer Service Phone Number: 502-562-0000

**HARDWARE LIST**

- |                                |                   |
|--------------------------------|-------------------|
| A (30) Allen Bolts 1/4" x 5/8" | E (2) Leg Panels  |
| B (30) Spring Washer 1/4"      | F (1) Leg Support |
| C (30) Flat Washer 1/4"        | G (1) Table Top   |
| D (1) Allen Wrench 1/4"        |                   |

**PARTS LIST**



- \* These components come in three sizes:  
Small, Medium & Large.



**IMPORTANT: Before assembly begins, match each same size component with one another to prevent using wrong parts during assembly.**

**STEP 1**

Begin assembly by attaching each Leg Support (F) to the inside of each same size Leg Panel (E) by aligning with the hole on each metal bracket and securing with 1 Allen Bolt (A), 1 Spring Washer (B) & 1 Flat Washer (C) per each end. Tighten all bolts using the Allen Wrench (D) that has been provided.


**STEP 2**

Attach each Table Top (G) to the top of each same size Leg Panels (E) by aligning holes and securing with 2 Allen Bolts (A), 2 Spring Washers (B) & 2 Flat Washers (C) per each corner. Tighten all bolts. The assembly is now complete.