

Assembly Instructions

ITEM NO. D4101-10T

PLATEAU 78" RECTANGLE DINING TOP

ITEM NO. D4101-10B

PLATEAU RECTANGLE TABLE PEDESTAL BASE




Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the PARTS LIST and/or HARDWARE LIST shown below.







Please read the instructions thoroughly before assembly.


1. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not tighten screws or bolts until the assembly is completed.
3. To level the chairs or table, before tightening all the screws, the chairs or table must be placed on a flat surface and then tighten the screws.
4. Please put all parts on a non-abrasive floor before assembly and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST

NO.	COMPONENT	SKETCH	QTY
A	TABLE TOP		1 PC
B	MOUNTING PLATE		2 PCS
C	LEG		2 PCS

HARDWARE LIST

NO.	COMPONENT	SKETCH	QTY
1	FLAT WASHER 5/16" DIA.		24 PCS
2	SPRING WASHER 5/16" DIA.		24 PCS
3	SHORT BOLT 5/16" x 1 3/8"		24 PCS
4	ALLEN KEY 5/32"		1 PC



Assembly Instructions

ITEM NO. D4101-10T


PLATEAU 78" RECTANGLE DINING TOP

ITEM NO. D4101-10B

PLATEAU RECTANGLE TABLE PEDESTAL BASE


STEP 1

Assemble the mounting plate (B) to the leg (C) by using the Allen key (4) with hardware 1, 2, and 3.



STEP 2

Place the table top (A) upside down on a flat and clean surface. Assemble the mounting plate (B) to the table top (A) by using the Allen key (4) with hardware 1, 2, and 3.



STEP 3

Complete.

