

TELESCOPE CASUAL FURNITURE

Instructions For Replacing The Fabric In The Sling Style Furniture

1. Remove the plastic end plugs at both ends of the sling rails.
2. Cut the fabric in half.
3. Remove the fabric from the sling rails.
4. Remove the bolts that fasten the sling rails to the chair assembly.
The back bar will fall free or you will have to remove two screws to remove the back bar. Save the back bar, bolts, screws, and spacers to reassemble.
5. Place a few drops of liquid soap on the end of the dowel of the new cover and slip it back into the grooves in each sling rail, making sure the sling is facing in the proper direction. Replace the end plugs.
6. Reassemble the sling rails to the frame assembly using bolts and spacers saved. NOTE: Be sure to start all bolts before final tightening.
7. To insert the back bar turn the chair upside down on a smooth, non- marring surface.
8. You will need a spreader bar to secure the back bar into its correct position.
(You may find a spreader bar at a Telescope Retailer or you can purchase a heavy-duty spreader bar from a hardware store.) Place a piece of paper on each sling rail for protection against marring. Place a spreader bar between the sling rails just below where the back bar is to be inserted, leaving yourself room to work with the back bar. Insert one end of the back bar into slot/or screw. Tighten spreader bar enough to insert the other end of the back bar. Once back bar is in its proper location the spreader bar may be released.