








Components and Hardware List

Top	Shelf	Legs			
					
(A) 1 pc.	(B) 1 pc.	(C) 4 pcs.	#12315 - Sofa Table		
Allen Head Bolt Ø8 x 50mm 	Allen Head Bolt Ø6 x 15mm 	Lock Washer Ø9 x Ø13mm 	Flat Washer Ø8 x Ø20mm 	Bracket 19 x 22 x 30mm 	Allen Key 4 x 110mm 
(H1) 8 pcs.	(H2) 8 pcs.	(H3) 16 pcs.	(H4) 16 pcs.	(H5) 4 pcs.	(H6) 1 pc.


Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

To prevent possible scratches or damage, assemble on a soft and smooth surface such as a blanket or carpet.


Step 1: Attach the Brackets (H5) to the Legs (C) using the Flat Washer (H4), Lock Washer (H3) and Bolts (H2) as shown. Do not fully tighten until Step 4.



Step 2: Place the Top (A), upside down on soft and smooth surface. Attach three legs to the Top (A) using the Flat washer (H4), Lock washer (H3) and Bolts (H1). Do not fully tighten Bolts until fourth Leg has been attached.



Step 3: Insert the shelf into the notches of the Legs, attaching using the Flat Washers (H4), Lock Washer (H3) and Bolts (H2).



Step 4: Attach the final Leg to the Top and Shelf as shown in Step 2 and 3. Adjust all parts for correct fit if necessary and tighten all the Bolts with the Allen Key (H6).

Step 5: Carefully set the assembled Table upright.

