


## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**REVISION 0: 12/30/2024** 

710767 End Table

**PAGE 1 OF 11** 

## **ІТЕМ:710767**



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### Warning!!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

**30 MINUTES** 

### **PARTS IDENTIFICATION**



#### **NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

**PAGE 2 OF 11** 



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

**30 MINUTES** 

### PARTS IDENTIFICATION

D FRONT AND BACK BOTTOM CROSSBAR



2 PCS

**E SIDE BOTTOM CROSSBAR** 



2 PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



### HARDWARE IDENTIFICATION


1	LARGE CAMBOLT (Ø7 x29mm)	12pcs
2	LARGE CAMBOLT (Ø15x12mm)	12pcs
3	WOOD DOWEL ( Ø8 x 40mm)	8pcs
4	SMALL CAMBOLT (Ø6 x20mm)	16pcs
5	SMALL CAMBOLT (Ø12x10mm)	16pcs
6	WOOD DOWEL (Ø6 x 30mm)	4pcs
7	STICKER (Ø22mm)	12pcs

#### NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



# ASSEMBLY INSTRUCTIONS STEP 1




### STEP 2



PAGE 5 OF 11




# ASSEMBLY INSTRUCTIONS STEP 3



**X2** 


### STEP 4




PAGE 6 OF 11



# ASSEMBLY INSTRUCTIONS STEP 5




### STEP 6




**PAGE 7 OF 11** 



# ASSEMBLY INSTRUCTIONS STEP 7




### STEP 8




PAGE 8 OF 11



# ASSEMBLY INSTRUCTIONS STEP 9




### **STEP 10**



PAGE 9 OF 11




# ASSEMBLY INSTRUCTIONS STEP 11



PAGE 10 OF 11




### **DIMENSION**





## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**REVISION 0: 12/30/2024** 

710768 Coffee Table

**PAGE 1 OF 11** 

## **ІТЕМ:710768**



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### Warning!!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

**30 MINUTES** 

### **PARTS IDENTIFICATION**



#### **NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

**PAGE 2 OF 11** 



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

**30 MINUTES** 

### PARTS IDENTIFICATION



#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



### HARDWARE IDENTIFICATION


1	LARGE CAMBOLT (Ø7 x29mm)	12pcs
2	LARGE CAMBOLT (Ø15x12mm)	12pcs
3	WOOD DOWEL ( Ø8 x 40mm)	8pcs
4	SMALL CAMBOLT (Ø6 x20mm)	16pcs
5	SMALL CAMBOLT (Ø12x10mm)	16pcs
6	WOOD DOWEL (Ø6 x 30mm)	4pcs
7	STICKER (Ø22mm)	12pcs

#### NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



# ASSEMBLY INSTRUCTIONS STEP 1



### STEP 2




PAGE 5 OF 11




**X2** 

# ASSEMBLY INSTRUCTIONS STEP 3



## STEP 4




PAGE 6 OF 11




## **ASSEMBLY INSTRUCTIONS**

STEP 5




### STEP 6




**PAGE 7 OF 11** 



# ASSEMBLY INSTRUCTIONS STEP 7




### STEP 8




PAGE 8 OF 11



# ASSEMBLY INSTRUCTIONS STEP 9




### **STEP 10**



**PAGE 9 OF 11** 



# ASSEMBLY INSTRUCTIONS STEP 11



PAGE 10 OF 11



### **DIMENSION**

