

Item #: YS500TT/YS500TL

Description: YVES DINING TABLE TOP/TABLE LEGS

Product Size: 40" x 77"-95" x 30" H (18" Take off Leaf)

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean with the grain of the wood.
- removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause - It is recommended to seal the tops on a regular basis (every 6 to 12 months). extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face recommendation. of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a - Dust with a soft cloth. Dust will scratch the furniture surface if not generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
 - * Keeping them free of debris or sharp objects
- * Wiping up spills immediately
- *Avoiding contact with chemicals(particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a hight gloss surface) by buffing with special stone polish, powder or cream.

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)


Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- A good quality stone sealer can be purchased from any tiles / stone store or any
- homecare store and should be applied according to the manufacturer's
- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

Caring for the Fabric on Upholstered Furniture:


- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- When wiping down the table, a soft, clean rag should be used. Do not Do not use cleaning products containing brightening agents.



YS500TT/YS500TL ASSEMBLY INSTRUCTIONS


DO NOT FULLY TIGHTEN ALL HEX BOLTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED

Step 1: Place Table Top (A) upside down on a piece of cloth or carpet to prevent finish from scratching Attach Table Leg (B) to the Table Top (A) by inserting Hex Bolt (1), Flat Washer (3), Lock Washer (2) and fully tighten with Wrench (4). Do not over tighten.




Step 2: Turn the Table to upright position. (*Note: It is recommended to use two or more people to turn the table).

Place the Table on flat surface. Unlock the Latch underneath the Table Top (A), and pull the Table Top (A) from both ends. Inserting the Table Leaf (C) into the middle of Table Top (A), close the Table Top (A) by pushing from both ends. Lock the Latch underneath the Table Top (A) to prevent from sliding. Assembly of product is now completed.




PART LIST



HARDWARE PACK #: PYS500TH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Hex Bolt		$\Phi^{1/4}$ " x 45 mm	12 pcs
2	Lock Washer		$\Phi^{5/16}$ " x 13 mm	12 pcs
3	Flat Washer		$\Phi^{5/16}$ " x 19 mm	12 pcs
4	Wrench		12 mm	1 pc

PARTS FOR YS500TT/YS500TL COMPLETE HARDWARE # : PYS500TH



PRODUCT DETAILS

TOP
APRON
TABLE LEG
PRODUCT SIZE
CARTON SIZE TOP
CARTON SIZE BASE
NET WEIGHT TOP
NET WEIGHT BASE
GROSS WEIGHT TOP
GROSS WEIGHT BASE
CU.FT. TOP
CU.FT. BASE

MDF / ASH VENEER
MDF / ASH VENEER
MANGO WOOD
40" X 77"- 95" X 30"H (18" take off leaf)
80.71" x 43.70" x 6.50"H
42.52" x 32.48" x 12.60"H
103.4 LBS
40.7 LBS
116.6 LBS
50.6 LBS
13.26'
10.07'

MADE IN VIETNAM



Item #: YS500SW / YS500SG

Description: YVES PERFORMANCE CHAIR WHITE/GREY

Product Size: 20" x 25.5" x 40" H

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean with the grain of the wood.
- removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in marble surfaces the same as wood surfaces is a great rule of thumb. the path of hot streams of air from central heating. This will cause - It is recommended to seal the tops on a regular basis (every 6 to 12 months). extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face recommendation. hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a - Dust with a soft cloth. Dust will scratch the furniture surface if not generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
- * Keeping them free of debris or sharp objects
- * Wiping up spills immediately
- *Avoiding contact with chemicals(particularly acid-based materials)
- Soap and water are not advisable for wood surfaces. Water can Clean with pH neutral products or those especially formulated for use on stone.
 - It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
 - After a period of use, apply a penetrating sealer to prevent contaminants from being
 - Remove stains with special absorbent poultices formulated for use on stone.
 - Renew the surface on polished granite (granite with a hight gloss surface) by buffing with special stone polish, powder or cream.

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

Marble Top Maintenance:


Marble may be stone, but it is porous stone and can stain easily. Treating

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's

of the table, which will resist ice, water, wine, liquor, food, cleaning - When sealed properly, marble tops can be used indoors and outdoors and can fluids, and warm or hot liquids; however, cups, glasses, etc. containing withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.


Caring for the Fabric on Upholstered Furniture:

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- When wiping down the table, a soft, clean rag should be used. Do not Do not use cleaning products containing brightening agents.




YS500SW / YS500SG ASSEMBLY INSTRUCTIONS

DO NOT FULLY TIGHTEN ALL BOLTS AND HEX NUTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLE




Step 1: Place the Chair Back (A) on the floor. Attach Seat Box w/Seat Cushion (B) to the Chair Back (A) by inserting the Short Bolt (2), Lock Washer (3), Flat Washer (4) into the holes at the rear bar of the seat frame. Attach Long Bolt (1), Lock Washer (3), Flat Washer (4) into the holes at the rear corner block of the seat box. Tighten all Bolts with Wrench (6). Do not fully tighten.

Step 2: Attach the Front Leg (C) to Seat Box w/ Seat Cushion (B) by inserting Hex Nut (5), Lock Washer (3), Flat Washer (4) and secure by Wrench (6). Do not fully tighten.



<u>Step 3:</u> Place the Chair to upright position on flat surface and adjust legs until level and does not wobble Fully tighten all bolts and hex nuts with Wrench (6). Assembly of product is completed.




PART LIST

(A) CHAIR BACK	(B) SEAT BOX w/ SEAT	(C) FRONT LEG
(1PC)	CUSHION (1PC)	(2PCS)

HARDWARE PACK #: PYS500SH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Long Bolt		$\Phi^{1/4}$ " x 75 mm	4 pcs
2	Short Bolt		$\Phi^{1/4}$ " x 40 mm	3 pcs
3	Lock Washer		$\Phi^{5/16}$ " x 13 mm	11 pcs
4	Flat Washer		$\Phi^{5/16}$ " x 19 mm	11 pcs
5	Hex Nut		$\Phi^{5/16}$ " x 12 mm	4 pcs
6	Wrench		12 mm	1 pc

PARTS FOR YS500SW / YS500SG COMPLETE HARDWARE # : PYS500SH



FABRIC CONTENT: 100% POLYESTER FIBER

This fabric is not machine washable
Allow +/- 3% residual shrinkage
Do not use cleaning products containing brightening agents

PRODUCT DETAILS			
CHAIR BACK SEAT BOX	MANGO WOOD/ACACIA WOOD ACACIA WOOD/ RUBBER WOOD		
FRONT LEG	ACACIA WOOD		
PRODUCT SIZE CARTON SIZE	20"x 25.5"x 40"H 41.53" x 20.27" x 16.34"		
NET WEIGHT	39.6 LBS/ 2PCS		
GROSS WEIGHT	46.2 LBS/ 2PCS		
CU.FT.	7.96' / 2PCS		

MADE IN VIETNAM

Steve Silver Company Dining Chairs- **Assembly Troubleshooting Guide**

The most important element of correct chair assembly is to tighten the bolts as directed. Prematurely tightening the bolts can lead to numerous issues and will lengthen the assembly time. Listed below are the most common issues in chair assembly and their easy solutions.

PROBLEM: Chair is unlevel.

Cause 1:

Unlevel chairs can occur if the bolts are fully tightened before all bolts are attached. There is a variance in the alignment of this chair to allow the chair to be assembled more easily.

Solution:

Loosen each bolt in the seat box (front legs, back corner blocks and back apron) until they are finger tight. Place the chair upright on the floor. Sit in the chair for about 30 seconds. Carefully turn the chair upside down and tighten each bolt. The chair will now be level.

Cause 2:

Unlevel chairs can occur if one or more of the floor glides are missing from the bottom of the chair leg.

Solution:

Request a set of floor glides from the e-mail address below.

AR@ssilver.com

PROBLEM: Bolts do not fit properly.

Cause:

This issue can occur when the bolts are tightened fully before all bolts are attached. There is a variance in the alignment of the bolts to allow the chair to be assembled more easily. Tightening the bolts prematurely can cause the holes for the other bolts to become slightly misaligned, causing the remaining bolts not to fit properly.

Solution:

Make sure each bolt in the seat box (front legs, back corner blocks and back apron) is loosened until finger tight. This will allow you to realign the holes, and the bolts will now fit properly.

Questions?

Please call us at 1 800 344 7278, and we will be happy to help you.



Item #: YS500SV

Description: YVES SERVER

Product Size: 60" x 18" x 36" H

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean with the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
 - * Keeping them free of debris or sharp objects
 - * Wiping up spills immediately
- *Avoiding contact with chemicals(particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a hight gloss surface) by buffing with special stone polish , powder or cream .

Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.


- It is recommended to seal the tops on a regular basis (every 6 to 12 months).

A good quality stone sealer can be purchased from any tiles / stone store or any homecare store and should be applied according to the manufacturer's recommendation.

- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

Caring for the Fabric on Upholstered Furniture:


- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
 - Do not use cleaning products containing brightening agents.



YS500SV ASSEMBLY INSTRUCTIONS


DO NOT FULLY TIGHTEN ALL HEX BOLTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED

Step 1: Place the Server (A) upside down on a piece of cloth or carpet to prevent finish from scratching. Attach Metal Leg (B) to the Server (A) by inserting Hex Bolt (1), Flat Washer (3), Lock Washer (2) and fully tighten with Wrench (4). Do not over tighten.




Step 2: Turn the Server to upright position. (*Note: It is recommended to use two or more people to turn the Server). Place the Server on flat surface and adjust the Leveler under the Metal Legs (B) until level and does not wobble.

- Open the Doors, remove the Handles by unfasten the Handle's Bolts and attach it to the outside of the Doors by using Phillips-head screwdriver (not provided) as the picture shown.
- The Tipping Restraint (5) is stapled at the back of Server (A). Thread Tipping Restraint (5) through the slots of the Server (A) to fasten and lock as the picture shown. Assembly of product is now completed.




PART LIST



HARDWARE PACK #: PYS500SVH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Hex Bolt		$\Phi^{1/4}$ " x 25 mm	8 pcs
2	Lock Washer		$\Phi^{5/16}$ " x 13 mm	8 pcs
3	Flat Washer		$\Phi^{5/16}$ " x 19 mm	8 pcs
4	Wrench		12 mm	1 pc
5	Tipping Restriant			1 set

PARTS FOR YS500SV COMPLETE HARDWARE # : PYS500SVH



PRODUCT DETAILS			
TOP APRON DOOR SHELF WINE RACK LEG PRODUCT SIZE CARTON SIZE NET WEIGHT GROSS WEIGHT CU.FT.	MDF / ASH VENEER MDF / ASH VENEER/ MANGO WOOD MANGO WOOD / TEMPERED GLASS MDF / LOCAL VENEER MDF / LOCAL VENEER METAL 60" x 18" x 36" H 62.79" x 20.87" x 34.84" H 155.1 LBS 173.8 LBS 26.42'		

MADE IN VIETNAM