



Ranges present a tip-over hazard that can be extremely dangerous, especially to any setting with children. All Summit ranges ship with an anti-tip bracket.

**Failure to install the anti-tip bracket can result in death or serious burns to children or adults.**

The bracket helps to prevent the range from tipping forward if excess weight is applied to an open oven door. It is strongly recommended that you install the anti-tip bracket when installing your range.

For a replacement anti-tip bracket, call our Parts Department at **718-893-3900 ext. 598**