



ITEM NO: I3048-332 Door Bookcase

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.

**WARNING!** Before using this product, please read, understand, and follow these instructions. Failure to follow each of these assembly instructions precisely may result in damage to the product and / or injury to the consumer.



**UNIT SHOULD BE INSTALLED BY 2 OR MORE PERSONS.**



**TOOLS REQUIRED (NOT PROVIDED)**

PHILLIPS SCREWDRIVER

**HARDWARE LIST:**


No.	Description	Sketch	Quantity
A	Hex Nut Ø5/16"		8 PCS
B	Lock Washer Ø5/16"		8 PCS
C	Flat Washer Ø5/16" x 3/4"		8 PCS
D	Hex Wrench 12mm		1 PC

**COMPONENTS LIST:**

No.	Description	Sketch	Quantity
1	Case		1 PC
2	Leg		4 PCS

**STEP 1:** Put the case backside down on a soft surface.

**STEP 2:** Attach the legs to the case by using 8 flat washers (C), lock washers (B) with hex nuts (A). Use the Hex wrench (D) provided to tighten all the bolts.




FOR INDOOR USE ONLY




ITEM NO: I3048-332 Door Bookcase



**STEP 3:** Return the case to the upright position.



### FUNCTIONALITY INSTRUCTION



**STEP 4:** Take off one screw from each mounting plate and swing it to the proper location on the other bookcase before re-securing it with the screw.



If you prefer to adjust the shelf location, remove the screws and move shelf brackets to the desired location. Then secure the brackets to shelf with screws.

Adjustable Wood Shelves

Adjust the levelers when necessary

Levelers on Legs