



B3399-SECT (28, 231, 33) in leather 659-70


FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 01/24

17		
18		
19		
231		
25		
26		
255		
265		
27		
28		
29		
33		
34		
37		
38	23	
●		Flexsteel Spring Unit
	●	Blue-Ribbon
		Sinuous Wire
●	●	Back Construction
		Loose-Pillow
●	●	Seat Construction
		Removable
●	●	Seat Cushion(s)
		Plush (PC)
●	●	Wood Finish
		Urban Renewal (R)
		All other wood finish options are available.

- Standard
- Optional

PRODUCT DIMENSIONS	OVERALL			SEAT			Arm Height
	Height	Width	Depth	Height	Width	Depth	
LAF Chair -17	35"	33"	38"	20"	25"	21"	25"
RAF Chair -18	35"	33"	38"	20"	25"	21"	25"
Armless Chair -19	35"	26"	38"	20"	26"	21"	
Full Wedge -23	35"	67"	38"	20"	45"	21"	
Corner Chair -231	35"	37"	38"	20"	21"	21"	
LAF Chaise -25	35"	34"	68"	20"	27"	52"	25"
RAF Chaise -26	35"	34"	68"	20"	27"	52"	25"
LAF Angled Chaise -255	35"	64"	51"	20"	44"	21"	25"
RAF Angled Chaise -265	35"	64"	51"	20"	44"	34"	25"
LAF Loveseat -27	35"	57"	38"	20"	50"	21"	25"
RAF Loveseat -28	35"	57"	38"	20"	50"	21"	25"
Armless Loveseat -29	35"	50"	38"	20"	50"	21"	
LAF Corner Sofa -33	35"	95"	38"	20"	73"	21"	25"
RAF Corner Sofa -34	35"	95"	38"	20"	73"	21"	25"
LAF Sofa -37	35"	81"	38"	20"	74"	21"	25"
RAF Sofa -38	35"	81"	38"	20"	74"	21"	25"




Connecting Clips
A connecting clip is attached to one sectional piece to allow the frame of a second piece to slide neatly down into the clip to secure the two pieces together.

B3399 Bryant Sectional | Components & Configurations


Leather Furniture

Components


LAF = Left-Arm-Facing
RAF = Right-Arm-Facing




B3399-33
LAF Corner Sofa




B3399-34
RAF Corner Sofa




B3399-37
LAF Sofa




B3399-38
RAF Sofa




B3399-27
LAF Loveseat




B3399-28
RAF Loveseat




B3399-29
Armless Loveseat




B3399-255
LAF Angled Chaise




B3399-265
RAF Angled Chaise




B3399-23
Full Wedge




B3399-231
Corner Chair




B3399-25
LAF Chaise




B3399-26
RAF Chaise



B3399-17
LAF Chair



B3399-18
RAF Chair



B3399-19
Armless Chair

Scale 1/4"=1'







Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 6/22
FLX-CP-FS-CC-B3399

FLEXSTEEL®

B3399 Bryant Sectional | Components & Configurations

Leather Furniture

Sample Configurations



Scale 1/4"=1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 6/22
FLX-CP-FS-CC-B3399

FLEXSTEEL®