




ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

703267
End Table

REVISION 0: 12/21/2018
REVISION 1: 07/02/2019
REVISION 2: 08/04/2022

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: 703267



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION


A TOP

1PC




B BASE

1PC




C GLASS

1PC



D SIDE PANEL

4PCS



Z HARDWARE IDENTIFICATION

1 ROD

4PCS



M8 *330

3 ROD NUT

4PCS



4 WASHER

4PCS



2 WOOD DOWEL

8PCS



Ø8*30

6 WOOD PLUG

1PC




M5

ITEM: 703267


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: 703267



ASSEMBLY INSTRUCTIONS



STEP 3




STEP 4



ITEM: 703267


ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

703268
Coffee Table

REVISION 0: 12/21/2018
REVISION 1: 07/02/2019
REVISION 2: 10/10/2020
REVISION 3: 08/04/2022

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: 703268







ASSEMBLY INSTRUCTIONS

- ASSEMBLY TIPS:**
- 1. Remove hardware from box and sort by size.
 - 2. Please check to see that all hardware and parts are present prior to start of assembly.
 - 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.
- WARNING!**
- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
 - 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION

A	TOP	1PC	C	GLASS	1PC
					
B	BASE	1PC	D	SIDE PANEL	4PCS
					

Z HARDWARE IDENTIFICATION


1	ROD	4PCS	3	ROD NUT	4PCS
					
	M8*330		4	WASHER	4PCS
2	WOOD DOWEL	8PCS			
			6	WOOD PLUG	1PC
	Ø8*30				
				M5	

ITEM: 703268


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: 703268


ASSEMBLY INSTRUCTIONS



STEP 3




STEP 4



ITEM: 703268

ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$