




Components and Hardware List

Top	Leaf	Legs	
 A 1pc.	 B 1pc.	 C 4pcs.	
 D 1pc.	 E 8pcs.	 F 8pcs.	 G 8pcs.
Allen Wrench 5mm	Ø5/16-18 x 2-1/2 Long Bolt	Lock washer Ø5/16" x Ø12 x 3mm	Flat washer Ø5/16" x Ø19 x 2mm



44450 Rect Leg Dining Table

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. **ASSEMBLY STEPS:**

1. Carefully place the Table Top upside down on a clean, soft surface such as a blanket or carpet.
2. Place the Legs (F) in the corner of the Table Top and attach with two Bolts (E), Spring Washers (F) and Flat Washers (G). Tighten with the Allen Wrench (D).
3. Using two people, carefully lift the completed table and set upright.

When installing or removing the Leaf, after unlocking the catches on the underneath side of the Table Top, lift the table off the floor and pull apart. Remove or add the leaf, slide the Table Top back together and re-lock the catches underneath.

Note: To prevent undue stress on the table and legs, if moving table, always use two people and carry the table from one location to the other.

