

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

206364
Mirror

ITEM: **206364**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A	MIRROR		1PC	C	MIRROR SUPPORT (PACKED WITH MIRROR)		2PCS
B	DRESSER FROM BOX ITEM #206363		1PC				

HARDWARE IDENTIFICATION

1	SHORT BOLT (M6 x 35mm - BLK)		4PCS	4	FLAT WASHER (1/4"ID x 19mm - BLK)		8PCS
2	LONG BOLT (M6 x 40mm - BLK)		4PCS	5	ALLEN WRENCH (M4 x 60MM - BLK)		1PC
3	LOCK WASHER (1/4" - BLK)		8PCS				


ITEM: **206364**



ASSEMBLY INSTRUCTIONS


STEP 1

ARROW MARKING FACE UPWARD



STEP 2

ARROW MARKING FACE UPWARD




****BACK VIEW****

ITEM: **206364**



ASSEMBLY INSTRUCTIONS

STEP 3




**ARROW MARKING
MUST BE ALIGNED**

STEP 4 **COMPLETE**



ITEM: 206364



Note: Dimension tolerance $\pm 5\%$