

ROUSSEAU COUNTER DINING TABLE ASSEMBLY INSTRUCTIONS



PARTS PACKING CONFIGURATIONS



A. TABLE TOP 1 PC

B. LEG B 2 PCS


C. LEG C 2 PCS

D. SIDE STRETCHER 2 PCS



E. BOTTOM SHELF 1 PC



Leg is labeled L






Leg is labeled R




HARDWARE PACKED IN BOX

No.	Description	Image	Quantity
1	ALLEN BOLT ($\frac{5}{16}$ " x 60mm)		8 pcs
2	ALLEN BOLT ($\frac{1}{4}$ " x 75mm)		4 pcs
3	LOCK WASHER ($\frac{5}{16}$ ")		12 pcs
4	FLAT WASHER ($\frac{5}{16}$ ")		8 pcs
5	FLAT WASHER ($\frac{1}{4}$ ")		4 pcs
6	ALLEN KEY		1 pc
7	HEX BOLT ($\frac{1}{2}$ " x 105mm)		4 pcs
8	FLAT WASHER ($\frac{1}{2}$ ")		4 pcs
9	HEX NUT ($\frac{1}{2}$ " x 19 mm)		4 pcs
10	WRENCH (19mm)		1 pc




STEP 1:




DO NOT FULLY TIGHTEN BOLTS

STEP 2:



DO NOT FULLY TIGHTEN BOLTS AND NUTS

STEP 3:



FULLY TIGHTEN ALL BOLTS AND NUTS IN STEPS 1, 2, & 3

ASSEMBLY COMPLETE

