



Components and Hardware List


Top Frame




Side Frame




Shelf




Allen Bolt
Ø1/4" x 1-1/2" L





Flat Washer
Ø1/4"



Spring Washer
Ø1/4"




Allen Wrench
4mm



73402

Rectangle Cocktail Table

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.



To remove the drawer if it ever becomes necessary:

A. Pull the drawer fully open so the black latch is visible in the inside channel of the guides.

B. Release the latches by simultaneously pushing one lever up and the other down.

C. At the same time, pulling the drawer forward until the slides release.

To reinstall the drawers, carefully align the channels of both guides and push drawer back in until fully closed. Open and close drawer fully a couple times to verify proper operation.

