ASSEMBLY INSTRUCTION


MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM CHILLER, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Bluetooth Connection: Enable Bluetooth on your device and pair with [GFUSA] from the list of available devices.

PARTS LIST:			
NO.	DESCRIPTION	SKETCH	Q'TY
A	Seat		1 PC
B	Backrest		1 PC
C	Left Wing		1 PC
D	Right Wing		1 PC



Made in Vietnam

ASSEMBLY INSTRUCTION


MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM CHILLER, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Step 1:

Attach the Backrest (B) to the Seat (A).




Step 2:

Attach the Wings (C/D) to the Left/Right side of the Backrest (B).



Step 3:



Made in Vietnam


ASSEMBLY INSTRUCTION

MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM CHILLER, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Step 4:



Setting Up


Please read the following instructions carefully
to install your new wine chiller properly and safely.

1. Let the wine chiller run empty for about 1 hour before storing any wine bottles inside.
2. This unit runs at its default temperature of 47°F/ 8°C. You can adjust the chiller's internal temperature by using the smart temperature controls on the LED display.
   a. Press ⌃ to increase your chiller's internal temperature.
   b. Press ⌄ to decrease your chiller's internal temperature.
   c. This unit has a temperature range between 47°- 65°F, or 8-18°C.
3. Press ⏻ to turn the interior blue LED light ON. Press the button again to turn it OFF.


NOTE ON COOLING: This cooling unit's actual internal temperature depends on the ambient temperature. While you can set the chiller's temperature within its operating range, its internal temperature may not reach the selected temperature if the surrounding temperature is too high.

Step 5:

Open the footrest or move the headrest by pressing the power button on/off.



1. LED Light Strip and Speaker On/Off
2. Type C
3. USB PORT
4. Open/Close recliner
5. Open/Close headrest
6. Home



Made in Vietnam

ASSEMBLY INSTRUCTION

MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM CHILLER, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

● Button Description

button	Button Name	Function
	*LED Light Strip and Speaker On/Off*	Short press: power on/off

● Instructions

1. Connect the product according to the assembly diagram and power it on.
2. Upon powering on, the product automatically starts. The light strip runs through a colorful cycle and then lights up blue.
3. The control button blinks blue, and a voice prompt says "Power On." At this point, the product enters Bluetooth pairing mode, and the voice prompt says "Wait for Pairing."
4. If Bluetooth fails to connect, the control button blinks blue rapidly, and the product automatically enters broadcast search mode. The Bluetooth search lasts for 10 seconds, followed by 5 seconds of broadcast search, and continues to cycle.
5. Open the Bluetooth function on your phone, TV, or other device, search for the Bluetooth name "GFUSA," and pair it. Once paired successfully, the voice prompt says "Bluetooth Connected," and the control button blinks blue rapidly, continuing the broadcast search.
6. Open the audio player on your device and start playing a *audio*. The speaker will automatically respond and play the audio. The light strip will default to the colorful cycle and will move with the rhythm of the audio. The subwoofer will also vibrate in sync with the audio's rhythm. When the audio pauses, the light strip lights up blue, and the subwoofer stops vibrating.
7. You can control the audio on your device, including previous track, next track, pause/play, volume down, and volume up.
8. Press the control button briefly to turn off the device, and the voice prompt will say "Power Off." Press the control button again briefly to turn the device on.
9. Bluetooth- enabled devices such as TVs, computers, and MP3 players can also connect to the Bluetooth speaker. Please refer to their user manuals to find and turn on Bluetooth, search for the Bluetooth name "GFUSA", and complete the pairing.

Made in Vietnam

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

B Broadcast function

1. Transmitter (Primary) settings

- Upon powering on, the product automatically enters Bluetooth search mode. After a successful Bluetooth connection, it will automatically switch to broadcast search mode. At this point, the product is in broadcast transmission mode. After the button blinks for 30 seconds, it will turn solid blue, but the broadcast will remain active.

2. Receiver (Secondary) pairing

- Power on another E309BLTVA01, and the product will enter Bluetooth search for 10 seconds, followed by 5 seconds of broadcast search, continuing in a loop. In broadcast search mode, it will automatically pair with the primary unit.
- Once paired successfully, the control button on the secondary unit will stay solid blue. At this point, the primary unit and secondary unit will sync: playing audio, the light strip will move in a colorful rhythm, and the subwoofer will vibrate with the audio.

3. Turn off the broadcast function

- Briefly press the control button on the primary unit to turn it off, and the voice prompt will say "Power Off." The primary unit will exit both broadcast and Bluetooth modes, and the secondary unit will be released, returning to Bluetooth search for 10 seconds, followed by 5 seconds of broadcast search, continuing in a loop.
- If you only need to turn off the broadcast mode on a single secondary unit, simply press the control button on that secondary unit to turn it off. The primary unit and other secondary units will remain in broadcast mode.

Remark:

- The first E309BLTVA01 successfully paired with the device will act as the primary unit for the broadcast function.
- Ensure there are no obstacles between the primary unit and the secondary unit when using the broadcast function for optimal sync playback.
- Light strip status: When audio plays, the light strip moves in a colorful pattern and follows the rhythm of the audio. When audio pauses or the audio volume is minimized, the light strip lights up blue.
- Subwoofer status: When audio plays, the subwoofer vibrates with the audio. When audio pauses, the subwoofer stops vibrating.
- This product does not support Bluetooth reconnecting functionality.

ASSEMBLY INSTRUCTION

MODEL: MVP-BLANCHE BLK-P2 R

DESCRIPTION: POWER RECLINER WITH POWER HEADREST, 2 ARM CHILLER, ACRYLIC BOARD, BEHIND EAR STORAGE AND IMMMERSE SOUND SPEAKER WITH LED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Product parameters

Power Input	DC20V4.5A
Speaker Output	12W*2
Vibration Output	12W*2
LED Output	10W

Common troubleshooting

Fault	Possible causes and solutions
Unable to power on	1. No power connection. 2. The wire is disconnected or the plug is not fully inserted. 3. The connected socket is faulty.
No sound	1. The extension cable of the speaker is disconnected, please check all the connections or reconnect them.
Bluetooth cannot connect	1. Already connected to another Bluetooth device , please restart the device and try again. 2. Beyond the effective range. Please do not connect beyond 8M of this product. Do not try to connect through obstacles. 3. The product enters broadcast mode, please restart it and try again .
The audio is played by another device	1. Please check whether the device is paired with two Bluetooth devices at the same time, unpair one of them, and click the play button on the device.
Broadcast connection failed	1, Please check if the receiver is connected to another Bluetooth connection. Please restart the receiver and try again. 2, Please check the lines to see if they are all connected. 3, 3. Please check whether the device is paired with two Bluetooth devices at the same time, unpair one of them, and click the play button on the device.

Made in Vietnam