ASSEMBLY INSTRUCTIONS

ITEM NO: B8180 - T - HBFB / FT - RAIL TWIN HEADBOARD / FOOTBOARD / SIDE RAIL

(BOX 1) BOX OF HEADBOARD / FOOTBOARD

ITEM	DRAWING	DESCRIPTION	QTY
A		HEADBOARD PANEL	1
В		LEFT HEADBOARD LEG	1
С		RIGHT HEADBOARD LEG	1
D		FOOTBOARD	1
E		WOODEN SLAT	4

(BOX 1) HEADBOARD / FOOTBOARD HARDWARE LIST

ITEM	DRAWING	DESCRIPTION	QTY
1		ALLEN WRENCH (M4)	1
2	97 9 000	CONNECTION BOLT (M6 x 50mm) W/WASHER & SPRING WASHER	8
3	9 9 000	CONNECTION BOLT (M6 x 25mm) W/WASHER & SPRING WASHER	8
4	8 Trans	FLAT HEAD SCREW (#8 x 1 1/8")	8
5		Assembly Tool Not Included	1




(BOX 2) BOX OF SIDE RAIL

ITEM	DRAWING	DESCRIPTION	QTY
F		SIDE RAIL	2

(BOX 2) SIDE RAIL HARDWARE LIST


ľ	ГЕМ	DRAWING	DESCRIPTION	QTY
	6		WOOD DOWEL (M8 x 30mm)	8



THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE : MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHNESS OF ALL SCREW EVERY 6-8 WEEKS.

CLEANING INSTRUCTION



THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE: MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHNESS OF ALL SCREW EVERY 6-8 WEEKS.

CLEANING INSTRUCTION