

ASSEMBLY INSTRUCTIONS

MODEL

FM7201-F

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED



Screwdriver (Not included)



Allen Wrench




2 - People

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



CHECK BEFORE STARTING

Are you missing anything?

Double-check all parts, hardware and accessories listed are all acccounted for.

Shoul	d	we

Are there any irregularities or flaws in the parts? We can send replacements!

send any replacements?

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.











ŝ.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.

Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



ASSEMBLY AND **CARE ADVICE**




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

thereafter.




FM7201-F is packed in 3 cartons


CARTON	DESCRIPTION	PART	HARDWARE
FM7201WH-F-HB	FULL HEADBOARD	1 x1	
	FULL HB - LEG RIGHT	(2) x1	
	FULL HB - LEG LEFT	3 - x1	D x 1 PC E x 1 PC
FM7201WH-F-FB	FULL FOOTBOARD	(4) x1	F x 8 PCS
	FULL SLAT	6 ×4	O G x 8 PCS D x 1 PC
	FULL VERTICAL	⑦ ◆ x4	H x 8 PCS
FM7201WH-F-R	FULL SIDE RAIL	5 / x2	

.....

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS







Incluse onder rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy! Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag! To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.