

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life


708419
Console Table

ITEM:708419

COASTER
FINE FURNITURE

STEP 1


* PLEASE REMOVE THE WOOD STRIP BEFORE USE.




NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

STEP 2 COMPLETE



ITEM: **708419**



Note : Dimension tolerance $\pm 5\%$