




ITEM NAME / NOM D'ITEM: CHARLESTON ACCENT CHAIR
ITEM #/NO. ITEM: 109524/109525

NO ASSEMBLY REQUIRED



Please use the attached adjustable footglides to level the chair on uneven surface

For missing parts or damaged parts, please call/
For pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico: (866) 798-6663

AI-V1-230828