



PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / NO D'ARTICLE / ARTICULO NO. : P359306

DESCRIPTION/ LA DESCRIPTION / DESCRIPCIÓN : SERVER / DESSESTE / APARADOR

AVERTISSEMENT	AWARNING	
Des enfants sont morts à cause du renversement de meubles. Pour réduire le risque de renversement des meubles: • Installez toujours le dispositif anti-basculement fourni. • Poids maximal recommandé pour les téléviseur, 75 lbs. (34kg). • NE JAMAIS laisser un enfant se tenir debout sur les tiroirs, les portes ou les tablettes, y grimper ou s'y suspendre. • N'ouvrez JAMAIS ouvrir plus d'un tiroir à la fois. • Mettre les objets les plus lourds dans les tiroirs du bas. Cette étiquette est permanent. Ne pas la retirer!	Children have died from furniture tipover. To reduce the risk of furniture tipover: • Always install anti-tip device provided. • Maximum recommended television weight, 75lbs. (34kg). • NEVER allow children to stand, climb, or hang on any drawers, doors or shelves. • Never open more than one drawer at a time. • Place heaviest items in the lowest drawers. This is a permanent label. Do not remove!	



A

x1 Accent server
x1 Dessete
x1 Aparador


B

x1 Furniture Tipping Restraint *
x1 Systeme antibasculement
x1 Control para evitar viltcos

* Replaceable Part


AVERTISSEMENT	WARNING	
Des enfants sont morts à cause du renversement de meubles. Pour réduire le risque de renversement des meubles: • Installez toujours le dispositif anti-basculement fourni. • Poids maximal recommandé pour les téléviseur, 75 lbs. (34kg). • NE JAMAIS laisser un enfant se tenir debout sur les tiroirs, les portes ou les tablettes, y grimper ou s'y suspendre. • N'ouvrez JAMAIS ouvrir plus d'un tiroir à la fois. • Mettre les objets les plus lourds dans les tiroirs du bas. Cette étiquette est permanente. Ne pas la retirer!	Children have died from furniture tipover. To reduce the risk of furniture tipover: • Always install anti-tip device provided. • Maximum recommended television weight, 75lbs. (34kg). • NEVER allow children to stand, climb, or hang on any drawers, doors or shelves. • Never open more than one drawer at a time. • Place heaviest items in the lowest drawers. This is a permanent label! Do not remove!	


STEP 1
ÉTAPE 1
PASO 1





★ Replaceable Part

⚠️AVERTISSEMENT	⚠️WARNING	
Des enfants sont morts à cause du renversement de meubles. Pour réduire le risque de renversement des meubles: • Installez toujours le dispositif anti-basculement fourni. • Poids maximal recommandé pour les téléviseur, 75 lbs. (34kg). • NE JAMAIS laisser un enfant se tenir debout sur les tiroirs, les portes ou les tablettes, y grimper ou s'y suspendre. • N'ouvrez JAMAIS ouvrir plus d'un tiroir à la fois. • Mettre les objets les plus lourds dans les tiroirs du bas. Cette étiquette est permanent. Ne pas la retirer!	Children have died from furniture tipover. To reduce the risk of furniture tipover: • Always install anti-tip device provided. • Maximum recommended television weight, 75lbs. (34kg). • NEVER allow children to stand, climb, or hang on any drawers, doors or shelves. • Never open more than one drawer at a time. • Place heaviest items in the lowest drawers. This is a permanent label. Do not remove!	




- 

x2 RP359306-SHELF-Wood Shelf
Étagère
Repisaj/ Estante
- 

x8 RP359302-HINGE-Door Hinge
Charnière de porte
Bisagra de la puerta
- 

x4 RP359302-CATCH-Door Catch
Catch de aimant
Captura de imán

- 

x8 RP359302-CLIP-Shelf Clip
Supports Pour
Tablette Soporte De las Repisas
- 

x6 RC-FG-WHITE-White Leveler
Patin réglable
Nivelador
- 

x4 RP359306-PULL - Pull with Screw
Poignée + vis
Tirador + Tornillo

- 

x1 RC-ANTI-TIP- Anti-tipping Restraint
Système antibasculement
Control para evitar vultcos

★ Replaceable Part

Protect Your Wood or Laminate Flooring

* This statement applies to any floor without carpet.

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floor without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.

** Replaceable Part*