

PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZA

ITEM / NO D'ARTICLE / ARTICULO.: S786-010

S786-030

DESCRIPTION/ DESCRIPCION : Dresser / Commode / Tocado

Mirror / Miroir / Espejo







⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



A

x1 Dresser
x1 Commode
x1 Tocado




B

x1 Mirror
x1 Miroir
x1 Espejo




C

x2 Mirror Support
x2 Pries en charge du miroir
x2 Soporte de espejo



D


x1 Furniture Tipping Restraint
x1 Système antiecullement
x1 Control para evitar vuelcos



3

x8 Flat washer Ø1/4"×19/2mm
x8 Rondelle plate Ø1/4"×19/2mm
x8 Arandela plana Ø1/4"×19/2mm


*



1

x8 Allen bolt Ø1/4" × 38mm
x8 Vis à tête creuse hexagonale Ø1/4" × 38mm
x8 Perno Allen Ø1/4" × 38mm

*



4

x1 Allen key M4
x1 Clé hexagonale
x1 Llave Allen

*



2

x8 Lock washer Ø1/4"×11/2mm
x8 Rondelle de blocage Ø1/4"×11/2mm
x8 Arandela de Seguridad Ø1/4"×11/2mm

*

*** Replaceable Part**

ASSEMBLY INSTRUCTION / NOTICE DE MONTAGE / INSTRUCCIONES DE MONTAJE

ITEM / NO D'ARTICLE / ARTICULO.: S786-010


S786-030

DESCRIPTION/ DESCRIPCION : Dresser / Commode / Tocado


Mirror / Miroir / Espejo

⚠ WARNING

	
Children have died from furniture tipover. To reduce the risk of furniture tipover: • ALWAYS install tipover restraint provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers. <i>This is a permanent label. Do not remove!</i>	




STEP 1
ÉTAPE 1
PASO 1



STEP 2
ÉTAPE 2
PASO 2

Furniture Tipping Restraint
Système antibasculement
Control para evitar vuelcos



Adjustable leveler
Patin réglable
Nivelador adjustable

* Replaceable Part

REPLACEABLE PART / PARTIE REMPLACABLE / PARTE REEMPLAZABLE

ITEM / NO D'ARTICLE / ARTICULO.: S786-010

S786-030

DESCRIPTION/ DESCRIPCION : Dresser / Commode / Tocado

Mirror / Miroir / Espejo




⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!




x14 RS786-010-KNOB-Knob with Screw
Poignée + Vis
Tirador + Tornillo

*



x1 RC-ANTI-TIP-Furniture Tipping Restraint
Système antioversement
Control para evitar vuelcos

*



x2 RC-FG-WHITE White Inlaid
Plaque à graine
Inserador

*



x4 RC-WH-NAL-White Plastic nail
clou en plastique
clavo de plástico

*



x1 RS786-030-HMWKT-Hardware kit kit
Lito des pièces de quincaillerie
Lito del kit de materiales

*



x2 RS786-030-MISU-Mirror Support
Supporte de miroir
Soporte del espejo

*



x10 COMGLIDE12-35-Dresser Glide
Glide
Deslizamiento del cajón

*

*** Replaceable Part**