




COMMERCIAL GAS DRYER

MODELS:

CGM2795JQ0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	W10906062	Knob	19	W10863352	Panel, Rear (Console)
	W11297002	Installation Instructions	10	W10492417	Skirt, Dial	20	3390647	Screw
	W10167625	Wiring Diagram	11	W10461071	Back Bracket, Non-Coin	21	8317339	Cover, Terminal Block
2	W11299025	Fascia	12	W10662107	Lamp, Indicator	22	98139	Screw
3	W10386302	Screw	13	W10424310	Switch, Push to Start	23		Top
4	W10492415	Knob	14	8533971	Screw		W10492414	White
5	W10133502	Indicator Lights Assembly	15	W10139100	Screw	24	W10153155	Harness, Main
6	W10510149	Bezel - PTS	16	W10327105	Switch, Cycle Selection			
7	W10492418	Cap, Knob	17	W11316903	Timer, Dryer			
8	W10155650	Nut, Hex	18	W11124005	Console			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3401797	Burner Assembly (60 Hz)	18		Panel, Front	37	8066134	Switch Assembly
				W10192882	White	38	3394881	Switch - Belt
2	8281911	Valve, Gas (Complete) 60 Hz	19	696144	Strike, Door	39	8066120	Lever Switch
			20	3387242	Seal, Front Panel	40	W10167612	Wire, Belt Switch
3	3389889	Bracket, Support	21	693152	Bumper	41	3398948	Wire, Jumper (Broken Belt Switch)
4	3387561	Clamp, Pipe	22	342055	Screw	42	98129	Screw
5	8529757	Bracket, Burner	23	3388229	Retainer	43	660658	Clamp, Motor
6		Cabinet	24		Panel, Toe	44	W10396031	Motor
	W10547697	White		697215	White	45	3393657	Restrainer, Belt
7	W10773242	Screw	25	3392538	Assembly, Door Catch	46	3394341	Pulley, Motor
8	345670	Lock Top	26	3390735	Seal, Door	47	3387118	Bracket, Motor
9	3391846	Clip, Front Panel	27	W10323061	Door, Rear	48	3390647	Screw
10	3391915	Screw	28	W10322546	Door, Front	49	693995	Screw
11	3406109	Switch, Door	29		Assembly, Hinge & Pin	50	W10869140	Cord, Power
12	697773	Screw		W10279703	Silver			DRYER EXHAUST KIT NOT INCLUDED
13	8283298	Jumper, Door Switch	30		Plug, Hinge		W10470674	Kit, 4-Way Venting
14	W10291934	Clip		W10191265	White			
15	W10561321	Foot, Dryer	31	W10116360	Handle, Door			
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	32	343641	Screw			
			33	W10131172	Belt, Drive			
			34	3389420	Screw			
16	3391943	Boot, Foot	35	W10344193	Pulley-Idler Assembly			
17	W10131123	Nut, "U"	36	W10446781	Spring, Idler			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10865336	Assembly, Air Duct	15	8066086	Plug, Drum Hole	31	3392519	Fuse, Thermal (91C)
2	693995	Screw	16	W10521118	Seal, Drum	32	W10178810	Thermostat
3	W11162462	Bulkhead, Rear	17	W10692558	Grill, Outlet	33	W10131836	Thermostat
4	3390647	Screw	18	3387230	Screw	34	8533971	Screw
5	W10001120	Nut, Hex (Left Hand Thread)	19	695240	Screw	35	8066224	Pipe, Exhaust
6	3387459	Washer	20	W10685669	Assembly, Outlet Housing	36	8572105	Clip, Exhaust
7	W10512946	Washer, Tri Ring	21	W10049370	Screen, Lint	37	8573824	Funnel, Burner
8	W10359272	Shaft, Drum Roller - Left Hand Thread	22	697557	Bulkhead, Front	38	338906	Sensor, Radiant
9	W10314171	Roller, Support	23	3357011	Screw	39	8573713	Cut-Off, Thermal
10	W10359271	Shaft, Drum Roller - Right Hand Thread	24	697814	Seal, Drum Front	40	3391912	Thermostat, Hi Limit
11	3934666	Nut, Hex	25	8066168	Assembly, Lint Duct	41	90767	Screw
12	W10545923	Assembly, Drum	26	489463	Screw	42	3401707	Jumper, Wire
13	697693	Baffle, Drum	27	W10345456	Clip, Spring			
14	W10219342	Screw	28	W10349492	Wheel, Blower			
			29	697770	Seal, Plate Cover			
			30	W10135254	Housing, Blower			

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	3401797	Burner Assembly (60 Hz)	11	694421	Screw, Coil	20	697441	Valve, Gas
2	688617	Tube, Burner	12	694538	Bracket, Coil	21	233076	Nut, Compression
3	694298	Bracket, Ignitor	13	694540	Coil, 60 Hz. (2 Terminal) (Main)	22	3393767	Pipe, Tail
4	686590	Ignitor	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)			Following Parts Not Illustrated
5	3393909	Screw				49572A		Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
6	343641	Screw						
7	3389871	Base, Burner	15	694424	Leak, Limiter			
8	3387057	Screw	16	694423	Screw, Regulator Adjustment			
9		Orifice, Burner	17	694422	Spring, Regulator			
	3397656	Type 1 (Natural Gas)						
10	8281911	Valve, Gas (Complete) 60 Hz	18	239822	Plug, Pipe			
			19	W10110395	Pipe, Gas Supply			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair
	8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)