

WINNERS ONLY[®]

Assembly Instructions

PROD.NO.:DKT35454T/DKT35454B

Thank you for purchasing this quality product. Please read instructions thoroughly before unpacking assembly parts.

Caution: Sharp, exposed staple tips can cause injury. Therefore, for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.




1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier and will help to prevent personal injury and to insure parts are not damaged during assembly process.





2. Before beginning, please check packing materials carefully for small parts that may have come loose inside the carton during shipping. Do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.

3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surface and also check for staples or nail left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.

4. Please do not over tighten screws or bolts. During normal use everyday screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and below mentioned components are attached to the furniture properly and kept tightened.


5. Please lay all parts and hardware on a non-abrasive surface such as a carpet and follow the assembly.

NO.	SKETCH	PARTS LIST	Q' ty
A		Table Top	1
B		Mounting Plate	1
C		Table Base	1

NO.		HARDWARE LIST	Q' ty
1		JCBC Ø5/16"*38mm	4
2		Ø5/16"-13mm Spring washer	4
3		Ø5/16"-19mm*2mm(T) Flat washer	4
4		Allen Key (4mm)	1

STEP 1: Use the Allen key (4) to remove the Mounting Plate (B) which is pre-attached underneath of the table top by removing six bolts. These bolts/ washers will be reused when you do the assembly at step 3.


TIP: Store the Allen key and Wrench in assembly in this product drawer or use masking or painter tap to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.




WINNERS ONLY[®]

Assembly Instructions


PROD.NO.:DKT35454T/DKT35454B






STEP 2: Attach the Mounting Plate (B) to the Table Base (C) using provided Hardware as show on FIG.2





STEP 3: Attach the Table top (A) to the Mounting plate (B) and the Table Base (C) using six bolts/washers from step 1



STEP 4: Turn the Table to upright position.



STEP 5: Unlock the hook underneath the table and slide table top halves wide open equally from both ends. Take off the center leaf and push table top from both ends to close, lock the hook underneath the table.



Assembly is now completed.