


**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**203504LED**  
***Led Mirror***

# ITEM: 203504LED

## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

## PARTS IDENTIFICATION


A MIRROR 1PC



B DRESSER 1PC  
FROM BOX ITEM # 203503



C MIRROR SUPPORT (PACK WITH DRESSER) 2PCS




D ADAPTER PLUG 1PC



## HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (M4 x 32mm - RBW) 10PCS



### NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **203504LED**




# ASSEMBLY INSTRUCTIONS

## STEP 1



## STEP 2




**\*\*BACK VIEW**

ITEM: **203504LED**



**ASSEMBLY INSTRUCTIONS**


**STEP 3**



**Arrow Marking  
Must Be Aligned**

**STEP 4**

**COMPLETE**




**ON & OFF  
TOUCH SWITCH**

**PLEASE REMOVE THE  
PROTECTIVE FILM  
BEFORE USE**



ITEM: 203504LED



**Note :** Dimension tolerance  $\pm 5\%$