

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223254 No. 100 No. 100

REVISION 0: 06/27/2018 REVISION 1: 04/22/2019 REVISION 2: 08/27/2019

ITEM: 223254

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR



1PC

DRESSER
B * FROM BOX ITEM #223253



1PC

C MIRROR SUPPORT (PACKED WITH MIRROR)



2PCS

HARDWARE IDENTIFICATION

1 BOLT (M6 x 35mm - BLK)



8PCS

LOCK WASHER (Ø13 x Ø6 x 1mm - BLK)



8PCS

3 FLAT WASHER (Ø16 x Ø6.5 x 1mm - BLK)



8PCS

Z-ALLEN WRENCH (4MM - WHT)




1PC

ITEM: 223254


ASSEMBLY INSTRUCTIONS








STEP 2 COMPLETE






Mi. 2020 / 09 / 19 SU

ITEM: 223254





Note: Dimension tolerance ±5%