



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

### 609560ARP POWER ARMLESS RECLINER

REVISION 0 : 6/15/2024  
REVISION 1 : 6/12/2025

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: **609560ARP**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

## PARTS IDENTIFICATION


|   |  |                        |      |
|---|--|------------------------|------|
| A |  | BASE                   | 1PC  |
| B |  | LEG                    | 4PCS |
| C |  | TRANSFORMER/POWER CORD | 1PC  |
| D |  | BACK CUSHION           | 1PC  |
| E |  | RECLINER BACK          | 1PC  |

ITEM: **609560ARP**




## ASSEMBLY INSTRUCTIONS


### STEP 1




### STEP 2





### STEP 3




### STEP 4 **COMPLETE**



ITEM:609560ARP



ITEM:609560ARP



Note:Dimension tolerance $\pm$ 5%