



ITEM NO: I644-6000 Round Dining Table

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.




TOOLS REQUIRED (NOT PROVIDED)
PHILLIPS SCREWDRIVER

HARDWARE LIST:			
No.	Description	Sketch	Quantity
A	Bolt Ø5/16" x 1"		8 PCS
B	Bolt Ø5/16" x 2"		6 PCS
C	Lock Washer Ø5/16"		14 PCS
D	Flat Washer Ø5/16" x 3/4"		14 PCS
E	Allen Wrench 4mm		1 PC

COMPONENTS LIST:			
No.	Description	Sketch	Quantity
1	Table Top		1 PC
2	Pedestal		1 PC
3	Top Stretcher		1 PC
4	Metal Support		2 PCS
5	Bottom Stretcher		1 PC


### FUNCTIONALITY INSTRUCTION



Adjust the leveler when necessary
-----------------------------------


BEFORE USING THIS PRODUCT PLEASE READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS. Save these instructions for future reference.

FOR INDOOR USE ONLY




ITEM NO: I644-6000 Round Dining Table

**STEP 1:** Attach the top stretcher to the pedestal by using 1 bolt (B), lock washer (C) and flat washer (D) as shown below. Do not tighten bolts until STEP 4.



**STEP 2:** Reverse the pedestal to the upside down as shown below.


**STEP 3:** Attach the metal supports to the pedestal by using 6 bolts (A), lock washers (C) and flat washers (D) with an allen wrench (E).






ITEM NO: I644-6000 Round Dining Table

**STEP 4:** Attach the bottom stretcher to the pedestal by using 2 bolts (A), 1 bolts (B), 3 lock washers (C) and 3 flat washers (D) as shown below. Use the allen wrench (E) to tighten all bolts.




**STEP 5:** Put the table top upside down on a soft surface, and attach the pedestal assembly to the table top by using 4 bolts (B), lock washers (C) and flat washers (D) as shown below. Use the allen wrench (E) to tighten all bolts. Turn the assembled table to the upright position.





ITEM NO: I644-6640S Dining Side Chair w/ Wood Seat (2/Ctn)

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.



**TOOLS REQUIRED (NOT PROVIDED)**

PHILLIPS SCREWDRIVER 


**HARDWARE LIST:**

No.	Description	Sketch	Quantity
A	Bolt Ø5/16" x 3-1/4"		4 PCS
B	Bolt Ø5/16" x 2"		4 PCS
C	Bolt Ø5/16" x 1-3/4"		2 PCS
D	Lock Washer Ø5/16"		10 PCS
E	Flat Washer Ø5/16" x 3/4"		10 PCS
F	Allen Wrench 4mm		1 PC
G	Wood Screw #4 x 1-1/2"		4 PCS

**COMPONENTS LIST:**

No.	Description	Sketch	Quantity
1	Chair Back		1 PC
2	Chair Seat		1 PC
3	Left Front Leg		1 PC
4	Right Front Leg		1 PC
5	"H" Stretcher		1 PC

FUNCTIONALITY INSTRUCTION



BEFORE USING THIS PRODUCT PLEASE READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS.


Save these instructions for future reference.

FOR INDOOR USE ONLY





ITEM NO: I644-6640S Dining Side Chair w/ Wood Seat (2/Ctn)


**STEP 1:** Attach the left front leg and right front leg to chair seat by using 4 bolts (B), lock washers (D) and flat washers (E), Do not completely tighten bolts.



**STEP 2:** Attach the chair seat to chair back by using 4 bolts (A), 2 bolts (C), 6 lock washers (D), 6 flat washers (E). Do not completely tighten bolts.




**STEP 3:** Attach the "H" stretcher to the front legs and chair back with wood screws (G). Completely tighten all wood screws and bolts. Turn the assembled chair to the upright position.





ITEM NO: I644-6660S Counter Side Chair w/ Uph Seat (2/Ctn)

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.



**TOOLS REQUIRED (NOT PROVIDED)**

PHILLIPS SCREWDRIVER 


**HARDWARE LIST:**

No.	Description	Sketch	Quantity
A	Bolt Ø5/16" x 3-1/4"		4 PCS
B	Bolt Ø5/16" x 2"		4 PCS
C	Bolt Ø5/16" x 1-3/4"		2 PCS
D	Lock Washer Ø5/16"		10 PCS
E	Flat Washer Ø5/16" x 3/4"		10 PCS
F	Allen Wrench 4mm		1 PC
G	Wood Screw #4 x 1-1/2"		4 PCS

**COMPONENTS LIST:**

No.	Description	Sketch	Quantity
1	Chair Back		1 PC
2	Chair Seat		1 PC
3	Left Front Leg		1 PC
4	Right Front Leg		1 PC
5	Left Side Stretcher		1 PC
6	Right Side Stretcher		1 PC

**FUNCTIONALITY INSTRUCTION**



BEFORE USING THIS PRODUCT PLEASE READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS.


Save these instructions for future reference.

FOR INDOOR USE ONLY





ITEM NO: I644-6660S Counter Side Chair w/ Uph Seat (2/Ctn)

**STEP 1:** Attach the left front leg and right front leg to chair seat by using 4 bolts (B), lock washers (D) and flat washers (E), Do not completely tighten bolts.



**STEP 2:** Attach the chair seat to chair back by using 4 bolts (A), 2 bolts (C), 6 lock washers (D), 6 flat washers (E). Do not completely tighten bolts.



**STEP 3:** Attach the left side stretcher and right side stretcher to the front legs and chair back with wood screws (G). Completely tighten all wood screws and bolts. Turn the assembled chair to the upright position.

