


## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

202990Q (B1-B3) Queen Bed

REVISION 0: 06/19/2012 REVISION 1: 09/21/2012 REVISION 2: 12/04/2012 REVISION 3: 01/21/2013 REVISION 5: 09/11/2016 REVISION 6: 12/04/2019 REVISION 6: 12/04/2019 REVISION 7: 08/04/2020 REVISION 8: 11/01/2023 REVISION 9: 03/12/2024

PAGE 1 OF 9



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

35 MINUTES

#### PARTS IDENTIFICATION

PARTS IDENTIFICATION			
<u>B1</u>	( BOX 1 )		
Α	HEADBOARD		1PC
B2 ( BOX 2 )			
В	FOOTBOARD		1PC
С	LEFT BED RAIL		1PC
D	RIGHT BED RAIL		1PC
B3 ( BOX 3 )			
E	CONCEAL PANEL		1PC
F	LEFT BED RAIL TOP		1PC
G	RIGHT BED RAIL TOP		1PC
н	FOOTBOARD TOP		1PC
ı	ROLL SLAT (7PCS)		2SETS
J	CENTER RAIL		1PC
		PAGE 2 OF 9	COASTERFURNITURE.COM



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

κ	CENTER RAIL SUPPORT WITH LEVELER	3PCS
L	BOTTOM TRESTLE BAR	3PCS
MF1	LIGHT SET WITH SCREW	1SET
Α	202990Q (B1) FROM BOX 1 HEADBOARD	1PC
В	202990Q (B2) FROM BOX 2 FOOTBOARD	1PC



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.


#### HARDWARE IDENTIFICATION


#### Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 202990Q (B1)


1	ALLEN WRENCH (M4 - BLK)		1PC
2	SHORT BOLT WITH WASHER (M6 x 30mm - BLK)	90000	10PCS
3	LONG BOLT WITH WASHER (M6 x 45mm - BLK)	97 <b>9</b> 00	10PCS
4	LONG BOLT (M6 x 45mm - BLK)	O Tamaman	16PCS
5	WOOD DOWEL (M8 x 30mm)		19PCS
6	ZIG ZAG SPRING CLICK (1.5 x 20.5 x 24 - BRN)		5PCS
7	SHORT FLAT HEAD SCREW (M4 x 16mm - BLK)	& Times	22PCS
8	BARREL NUT (M6 x 13mm - BLK)	<b>(4)</b>	10PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.








PAGE 6 OF 9


## ITEM: 202990Q (B1-B3) **ASSEMBLY INSTRUCTIONS** STEP 5 5.1 5.3 **D** 5.2 FRONT B **(C)** $(\mathbf{E})$ $\bigcirc$ (D)(8)**8** STEP 6 PUT WIRE HEAD TO BED INSIDE MF1 D 6.4 6.1 6 MF1 6.5 MF1 C $(\mathbf{F})$ MF1 MF1 MF1 MF1 MF1) (MF1) 6.2 6.3


PAGE 7 OF 9






# ASSEMBLY INSTRUCTIONS STEP 9 COMPLETE







Inner Size: 61.00"W x 81.00"D



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 202992 *Nightstand*

REVISION 0 : 06/18/2012 REVISION 1 : 09/11/2018 REVISION 2 : 12/04/2019 REVISION 3 : 07/05/2024

PAGE 1 OF 4



#### **ASSEMBLY INSTRUCTIONS**


#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

### **PARTS IDENTIFICATION**

A NIGHTSTAND




1PC

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

### **ASSEMBLY INSTRUCTIONS**

### STEP 1




PAGE 2 OF 4


### **ASSEMBLY INSTRUCTIONS**

## STEP 2





## STEP 3 COMPLETE







#### ANTI-TIPPING INSTALLMENT INSTRUCTIONS

#### **FURNITURE TIPPING RESTRAINT**

#### **WARNING**

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.











Inner Size of Drawer : 19.00"W x 12.75"D x 5.50"H x 0.50"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 202992P Nightstand Back Panel

REVISION 0 : 06/18/2012 REVISION 1 : 06/22/2012 REVISION 2 : 01/21/2013 REVISION 3 : 09/11/2018 REVISION 4 : 12/04/2019 REVISION 5 : 08/04/2020

PAGE 1 OF 4

## ITEM: 202992P



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

### **PARTS IDENTIFICATION**

A HEADBOARD EXTENSION PANEL



2PCS

### HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (M4 x 20MM - BLK)



32PCS

METAL PLATE 2 (3 x 25 x 90mm - BLK)



8PCS


METAL BRACKET 3 (2 x 25 x 110mm - BLK)



4PCS


#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




# ITEM: **202992P**ASSEMBLY INSTRUCTIONS STEP 3






## STEP 4 COMPLETE



**K** 

ITEM: **202992P** 





Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**202993** *Dresser* 

REVISION 0 : 06/18/2012 REVISION 1 : 09/11/2018 REVISION 2 : 12/04/2019 REVISION 3 : 07/05/2024

PAGE 1 OF 4



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

### **PARTS IDENTIFICATION**

A DRESSER



1PC


#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


PAGE 2 OF 4

## COASTER

## ASSEMBLY INSTRUCTIONS STEP 1



## STEP 2 COMPLETE







#### ANTI-TIPPING INSTALLMENT INSTRUCTIONS

#### **FURNITURE TIPPING RESTRAINT**

#### **WARNING**

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.










Inner Size of Drawer : 26.50"W x 12.75"D x 5.50"H x 0.50"T



Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

202994 *Mirror* 

REVISION 0 : 06/18/2012 REVISION 1 : 09/11/2018 REVISION 2 : 12/04/2019 REVISION 3 : 08/04/2020 REVISION 4 : 09/09/2023

PAGE 1 OF 4



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

#### **PARTS IDENTIFICATION**

Α	MIRROR	1PC
В	DRESSER *FROM BOX ITEM #202993	1PC
С	MIRROR SUPPORT (PACKED WITH DRESSER)	 2PCS

#### HARDWARE IDENTIFICATION


1	SHORT FLAT HEAD SCREW (M4 x 32mm - BLK)	O Trans	4PCS
2	LONG FLAT HEAD SCREW (M4 x 45mm - BLK)	O Think	4PCS

#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

# ITEM: 202994 ASSEMBLY INSTRUCTIONS STEP 1





#### STEP 2


#### (OPTIONAL)

Align and hang the mirror against the wall in landscape orientation with both left and right pre-fixed metal bracket in correct orientation.

**Note**: Screws or fittings to fix the mirror to the wall are not included. Choose screws or fittings that are suitable to the wall material and have sufficient holding power.


If you are uncertain, contact your local specialised retailer.

Warning: Wrong assembly can lead to the mirror topples or falls resulting in personal injury or damage.




# ITEM: 202994 ASSEMBLY INSTRUCTIONS STEP 3 COMPLETE











Note: Dimension tolerance ±5%