



2882-50H in fabric 147-02



Power Recliner with Power Headrest
2882-50H in 147-02



2882-50H in fabric 147-02

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 02/01/2024

53
51M
51H
51
50M
50H
50

FEATURES

Flexsteel Spring Unit

● DualFlex

Back Construction

● Attached

Seat Construction

● Attached

Seat Cushion(s)

● High-Density (HC)

Tailoring

○ Arm Covers

- Standard
- Optional

PRODUCT DIMENSIONS

	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Swivel Gliding Recliner -53	41"	34"	40"	20"	22"	22"	25"	65"	12"
Power Rocking Recliner -51M	41"	34"	40"	20"	22"	22"	25"	65"	12"
Power Rocking Recliner with Power Headrest -51H	41"	35"	43"	20"	22"	22"	25"	65"	14"
Rocking Recliner -51	41"	34"	40"	20"	22"	22"	25"	65"	12"
Power Recliner -50M	41"	34"	40"	20"	22"	22"	25"	65"	5"
Power Recliner with Power Headrest -50H	41"	35"	43"	20"	22"	22"	25"	65"	5"
Recliner -50	41"	34"	40"	20"	22"	22"	25"	65"	5"

NOTES

Available in more than 250 fabric options
 Also available in Performance fabrics - Revolution and LiveSmart
 Removable backs allow for easy lifting and maneuvering through doorways.
 Also available with nailhead trim (2881-50H)
 Swivels a full 360 degrees.
 Glides or reclines from any swivel position.
 Swivels in all directions while reclined.
 Safety locks prevent the furniture from gliding while reclining.
 Also available with nailhead trim (2881-53)
 Also available with nailhead trim (2881-51M)
 Safety locks prevent furniture from rocking while reclining.
 Also available with nailhead trim (2881-51H)
 Safety locks prevent the furniture from rocking while reclining.
 Also available with nailhead trim (2881-51)
 Also available with nailhead trim (2881-50M)
 Also available with nailhead trim (2881-50)
 The power control allows you to independently adjust the recline and headrest.
 A separate home button returns the headrest and footrest to their original positions with one touch.
 A USB port is included on the power control for powering electronics.
 Zero draw technology only uses power when the USB port is in use.
 Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.
 Power allows you to smoothly recline to any position.
 A single USB port is included on each power button control on styles with arms.



Power Recline & Headrest