

ASSEMBLY INSTRUCTION
INSTRUCCIONES

2631SET-LG/2631SET-DW COUNTER HIGH TABLE
2631SET-LG /2631SET-DW MESA ALTA DE MOSTRADOR


PARTS LIST
LISTA DE PARTES

1		1 PC/PIEZA
2		1 PC/PIEZA
3		1 PC/PIEZA
4		4 PCS/PIEZAS
5		2 PCS/PIEZAS


A		Bolt Ø1/4"*20*1-15/16"	12 PCS/PIEZAS
B		Allen key 4*60mm	1 PC/PIEZA
C		Screw 32mm	16 PCS/PIEZAS
D		FLAT WASHER 1/4"*19mm	16 PCS/PIEZAS
E		Ø10*20mm	2 PCS/PIEZAS
ASSEMBLY TOOL NOT INCLUDED			

ASSEMBLY INSTRUCTION
INSTRUCCIONES


Step 1




Step 2



Step 3



Step 4






DO NOT TIGHTEN ALL BOLTS UNTIL COMPLETELY ASSEMBLED.
NO APRETER LOS TORNILLOS HASTA ARMAR COMPLETAMENTE.

ASSEMBLY INSTRUCTION INSTRUCCIONES

2631SET-LG/2631SET-DW COUNTER HIGH CHAIR 2631SET-LG/2631SET-DW SILLA ALTA DE MOSTRADOR


PARTS LIST LISTA DE PARTES

1		1 PC/PIEZA
2		1 PC/PIEZA
3		2 PCS/PIEZAS R=1 L=1
4		1 PC/PIEZA
5		2 PCS/PIEZAS R=1 L=1


A		Bolt 1/4''*20*3-1/8" (chair back leg corner)	4 PCS/PIEZAS
B		Bolt 1/4''*20*1-1/2" (chair back center)	2 PCS/PIEZAS
C		Allen key 4*60mm	1 PC/PIEZA
D		Screw 45mm	6 PCS/PIEZAS
E		Hex Nut 5/16''*1/2"	4 PCS/PIEZAS
F		Lock Washer 5/16''*13mm	4 PCS/PIEZAS
G		Flat Washer 5/16''*19mm	4 PCS/PIEZAS
H		Wrench	1 PC/PIEZA
ASSEMBLY TOOL NOT INCLUDED			

ASSEMBLY INSTRUCTION INSTRUCCIONES


Step 1




Step 2



Step 3



Step 4



DO NOT TIGHTEN ALL BOLTS UNTIL COMPLETELY ASSEMBLED.
NO APRETER LOS TORNILLOS HASTA ARMAR COMPLETAMENTE.