# HARBY CONSOLE TABLE

ASSEMBLY INSTRUCTIONS



### PARTS AND FITTING PACKAGING DETAIL

BOX#1

A. TABLE TOP 1PC

B. LEGS 2PCS

C. CENTER RAIL 1PC

D. SUPPORT 2PCS

**BRACE** 










## HARBY CONSOLE TABLE ASSEMBLED




# **HARDWARE \* PACKED IN BOX #1**

H1	BOLT Ø5 X Ø50mm	8 PCS	H2	FLAT WASHERS 1 X Ø8 X Ø19mm	8 PCS
(I)			0		
НЗ	HEX WRENCH 12mm	1 PC	H4	SCREW Ø4 X Ø20mm	4 PCS
			(jamm>		
H5	SCREW Ø4 X Ø40mm	4 PCS			
	Jimimi				

## YOUR BOX MAY CONTAIN EXTRA HARDWARE

### STEP 1

Attach Legs (B) to Table Top (A) with Bolts (H1) and Washers (H2). Tighten using Hex Wrench (H3).



## STEP 2

Following the illustration, attach Center Rail (C) to Legs with Screws (H4). After securing Center Rail, attach Support Braces (D) to Table Top and to the Center Rail with Screws (H5). Screw Driver is not provided.

