

Specifications

1 model	SA-SW7
Summary	
WHAT'S IN THE BOX	AC Cord Reference Guide Warranty Card
Size & Weight	
SUBWOOFER SIZE (W X H X D) (MM)	352 x 358 x 134 mm
SUBWOOFER WEIGHT (KG)	6.2 kg
Amplifier	
AMPLIFIER TYPE	Digital Amplifier,S-Master
AMPLIFIER CHANNELS	1 ch
Speaker Layout	
SPEAKER STRUCTURE	Subwoofer
Wireless Features	
DUAL SUBWOOFER	Yes
Function with Bravia	
DIRECT CONNECT TO BRAVIA	Yes ²
Details	
POWER CONSUMPTION *APPROX	20 W
Eco and energy saving	
POWER CONSUMPTION (OFF MODE)	0.3 W
POWER CONSUMPTION (STANDBY MODE / LOW POWER MODE)	Not available
OFF MODE / STANDBY MODE / LOW POWER MODE ACTIVATED	After 20 minutes
POWER CONSUMPTION (NETWORK STANDBY MODE) – TERMINALS	1.8 W (Wireless Sound Specification, Bluetooth®, all terminals and networks connect
NETWORKED STANDBY MODE ACTIVATED – TERMINALS	After 20 minutes (Bluetooth® connection)
WIRELESS NETWORK(S) ON/OFF SWITCH	Press the LINK button 5 times

Standard View >

1

Price may not include "Provincial Environmental Handling Fee (EHF)". For more details see <https://www.recyclemyelectronics.ca/>.

2

This function works with compatible BRAVIA. https://www.sony.net/hav_faq

*

©2020 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. Sony, EXTRA BASS, BRAVIA, and BRAVIA CORE and its logos are trademarks of Sony Corporation. All other trademarks are trademarks of their respective owners. Features and specifications are subject to change without notice.

*

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under licence.