

Specifications

1 model	HT-B500 HT-B500
Summary	
WHAT'S IN THE BOX	*Note: HDMI cable not included ² AC Cord Batteries for remote commander Quick Setup Guide Reference Guide Remote Control Wall mounting template Warranty Card
Size & Weight	
MAIN UNIT SIZE - BODY ONLY (W X H X D)	900 x 64 x 100 mm
MAIN UNIT SIZE - BODY ONLY (W X H X D) (INCH)	35 1 / 2 x 2 5 / 8 x 4 in
MAIN UNIT WEIGHT - BODY ONLY	3 kg
MAIN UNIT WEIGHT - BODY ONLY (OZ)	6 lb 10 oz
SUBWOOFER SIZE (W X H X D) (MM)	192 x 388 x 400 mm
SUBWOOFER WEIGHT (KG)	7.3 kg
Amplifier	
AMPLIFIER TYPE	Digital Amplifier, S-Master
AMPLIFIER CHANNELS	3.1ch
Subwoofer	
SUBWOOFER TYPE	Wireless
Interface	
INPUT AND OUTPUT TERMINALS	Optical audio input
BLUETOOTH® VERSION	Bluetooth® version: 5.3 ³
BLUETOOTH® COMPATIBLE PROFILES	A2DP, AVRCP
BLUETOOTH® SUPPORTED CODECS	SBC, AAC
HDMI	
NUMBER OF INPUT/OUTPUT	Input / Output: - / 1 (eARC / Audio Return Channel)
EARC	Yes
BRAVIA SYNC	Yes
HDMI CEC	Yes
Audio Formats	
HDMI EARC	Dolby Digital, Dolby Digital Plus, Dolby TrueHD, Dolby Atmos, DTS, DTS ES, DTS 96 / X, LPCM: 2ch / 5.1ch / 7.1ch
OPTICAL INPUT	Dolby Digital, Dolby Digital Plus, Dolby Digital Plus / Atmos, DTS, DTS ES, DTS 96 / 2ch

1 model	HT-B500 HT-B500
BLUETOOTH® COMMUNICATION (RECEIVER)	AAC, SBC
Sound Function	
SOUND MODE	Sound Field (ON/OFF)
SOUND EFFECT	Night Mode,Voice Mode
VIRTUAL SURROUND TECHNOLOGY	S-Force PRO,Vertical Surround Engine
SOUND ENHANCEMENT TECHNOLOGY	DSEE
Speaker Layout	
SPEAKER STRUCTURE	3.1 ch (4 Speaker Units)
Application	
SONY BRAVIA CONNECT	Yes ³
Function with Bravia	
FUNCTION WITH BRAVIA	Voice Zoom 3™ ⁴ , Quick Settings
Details	
POWER CONSUMPTION *APPROX	Bar: 30 W, Subwoofer: 20 W
Eco and energy saving	
POWER CONSUMPTION (OFF MODE)	Bar: not available / Subwoofer: 0.3 W
POWER CONSUMPTION (STANDBY MODE / LOW POWER MODE)	Bar: 0.5 W / Subwoofer: not available
OFF MODE / STANDBY MODE / LOW POWER MODE ACTIVATED	Bar: after 20 minutes / Subwoofer: not available
POWER CONSUMPTION (NETWORK STANDBY MODE) – TERMINALS	Bar: 0.5 W (HDMI CEC), 2.0 W (Bluetooth® connection, all terminals and networks co Subwoofer: 0.5 W (Wireless Audio, all terminals and networks connected)
NETWORKED STANDBY MODE ACTIVATED – TERMINALS	Bar: after 20 minutes (HDMI CEC, Bluetooth® connection) / Subwoofer: after 20 min (Wireless Audio)
WIRELESS NETWORK(S) ON/OFF SWITCH	Bar: Press (Muting), (Volume) -, and (Volume) + in that order within 5 seconds on th remote control to turn on/off the Bluetooth® connection. / Subwoofer: not availabl

Standard View >

1 Price may not include "Provincial Environmental Handling Fee (EHF)". For more details see <https://www.recyclemyelectronics.ca/>.

2 Ethernet-enabled High Speed HDMI cable recommended.

3 The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license. Other trademarks and trade names are those of their respective owners.

4 This function works with compatible BRAVIA. https://www.sony.net/hav_faq

* ©2020 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. Sony, EXTRA BASS, BRAVIA, and BRAVIA CORE and its logos are trademarks of Sony Corporation. All other trademarks are trademarks of their respective owners. Features and specifications are subject to change without notice.

* The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under licence.