


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115112

Dining Side Chair

ITEM: **115112**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A RIGHT LEG FRAME



1PC

B LEFT LEG FRAME



1PC

C LONG RAIL



1PC

D SHORT RAIL



1PC

E SEAT CUSHION



1PC

F BACKREST



1PC

HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M4 x 110MM - BLK)



1PC

2 LONG BOLT
(M6 x 50MM - RBW)



4PCS

3 SHORT BOLT
(M6 x 35MM - RBW)



2PCS

4 LOCK WASHER
(1/4" - BLK)




6PCS

5 FLAT WASHER
(M6 X 13MM - RBW)



6PCS

6 PAN HEAD SCREW
(#8 x 1 1/4" - BLK)



4PCS

7 WOOD DOWEL
(M10 x 30MM)



2PCS

8 WOOD PLUG
(Ø14.5 X 9MM)



2PCS

NOTE :


Phillips head screw driver is required in the assembly process ; However, manufacturer not provide this item. Quantities shown are for one chair.

ITEM: **115112**


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: **115112**


ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4




ITEM: **115112**



ASSEMBLY INSTRUCTIONS




STEP 5



STEP 6 **COMPLETE**



ITEM: **115112**



Note : Dimension tolerance $\pm 5\%$