




ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

190721
7PC Dining Set

ITEM: **190721**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!






1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.












ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	TABLE TOP		1PC
B	TABLE LEG		4PCS
C	BACK FRAME		6PCS
D	SEAT CUSHION WITH FRAME		6PCS
E	FRONT LEG		12PCS


HARDWARE IDENTIFICATION

1	BOLT 3 (Ø5/16" x 2-1/4" - RBW)		8PCS	6	BOLT 1 (Ø1/4" x 1-1/2" - RBW)		6PCS
2	BIG LOCK WASHER (Ø5/16" - RBW)		8PCS	7	SMALL LOCK WASHER (Ø1/4" - RBW)		54PCS
3	BIG FLAT WASHER (Ø5/16" - RBW)		8PCS	8	SMALL FLAT WASHER (Ø1/4" - RBW)		54PCS
4	BOLT 4 (Ø1/4" x 3-1/4" - RBW)		24PCS	9	ALLEN WRENCH (4MM - RBW)		7PCS
5	BOLT 2 (Ø1/4" x 2-1/4" - RBW)		24PCS				


ITEM: **190721**

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **190721**




ASSEMBLY INSTRUCTIONS


STEP 3




STEP 4



STEP 5 COMPLETE




ITEM: **190721**



Note: Dimension tolerance $\pm 5\%$

ITEM: **190721**



Note: Dimension tolerance $\pm 5\%$