



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

915107
Accent Table

ITEM: 915107

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A


TOP



1PC

B


BASE




1PC

ITEM: **915107**
ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2



STEP 3
COMPLETE



ITEM: **915107**



Note : Dimension tolerance $\pm 5\%$