

**CLA-419-531 MEDIA MOGUL**  
**CARACOLE CLASSIC**

**ASSEMBLY INSTRUCTIONS**

**PLEASE UNPACK ALL PARTS AND CHECK QUANTITY AGAINST PARTS LIST BEFORE DISCARDING PACKING CARTON!**

Assembling Steps:

Step 1: Unpack the carton and put the media cabinet upright on a flat floor.

Step 2: Assemble door knob (B) and screw (C) according to the diagram.

Note: The screw driver for this step is not included in the hardware bag.

Step 3: Follow instruction for Anti-tip restraint assembly.

**\*\*\* NOTE KEEP THIS SHEET \*\*\***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Schnadig International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

CLA-419-531			
MEDIA MOGUL			
Part List			
Hardware List		Part Number	QTY
1		Door	<b>CLA-419-531-0393</b>
2		Adjustable Shelf	<b>CLA-419-531-024</b>
3		Adjustable Floor Glide	<b>CLA-419-531-075</b>

RTA Hardware			
Hardware List			QTY
A		Tip-Tilt Restraint Hardware Bag	<b>1</b>
B		Door Handle Hardware	<b>4</b>
C		Screw for Door Handle (6*15mm)	<b>12</b>

