



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

610521P
POWER RECLINING SOFA

ITEM : 610521P
ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION




PARTS LIST

A		LEFT BACK CUSHION	1PC
B		MIDDLE BACK CUSHION	1PC
C		RIGHT BACK CUSHION	1PC
D		BASE	1PC
E		LEFT EAR	1PC
F		RIGHT EAR	1PC
G		PLUG-IN POWER SUPPLY	1PC


STEP 1





STEP 2



STEP 3




STEP 4



Please follow below steps to install the 9V batteries when there is no power to operate the motion sofa.(Any model of 9V battery is applicable)


STEP 1

Open the marked battery door on the backup battery box.




STEP 2

Install two 9V batteries in the backup battery box.(batteries are not included)




STEP 3

Push the batteries in.



STEP 4



Close the box door.



Notice: Please don't keep the battery in the box when the power motion sofa is under daily use with power supply.

ITEM : 610521P

ASSEMBLY INSTRUCTIONS





ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

610522P
POWER RECLINING LOVESEAT

ITEM : 610522P
ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME







10 MINUTES

PARTS IDENTIFICATION



PARTS LIST

A		LEFT BACK CUSHION	1PC
B		MIDDLE BACK CUSHION	1PC
C		RIGHT BACK CUSHION	1PC
D		BASE	1PC
E		LEFT EAR	1PC
F		RIGHT EAR	1PC
G		PLUG-IN POWER SUPPLY	1PC

STEP 1**STEP 2****STEP 3****STEP 4****STEP 5**

ITEM : 610522P


ASSEMBLY INSTRUCTIONS



Please follow below steps to install the 9V batteries when there is no power to operate the motion sofa.(Any model of 9V battery is applicable)


STEP 1

Open the marked battery door on the backup battery box.




STEP 2

Install two 9V batteries in the backup battery box.(batteries are not included)



STEP 3


Push the batteries in.



STEP 4



Close the box door.

Notice: Please don't keep the battery in the box when the power motion sofa is under daily use with power supply.



ITEM : 610522P

ASSEMBLY INSTRUCTIONS





ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

610523P
POWER RECLINER

ITEM : 610523P

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION




PARTS LIST

A		BACK CUSHION	1PC
B		BASE	1PC
C		LEFT EAR	1PC
D		RIGHT EAR	1PC
E		PLUG-IN POWER SUPPLY	1PC


STEP 1





STEP 2



STEP 3



STEP 4



ITEM : 610523P


ASSEMBLY INSTRUCTIONS



Please follow below steps to install the 9V batteries when there is no power to operate the motion sofa.(Any model of 9V battery is applicable)


STEP 1

Open the marked battery door on the backup battery box.




STEP 2

Install two 9V batteries in the backup battery box.(batteries are not included)



STEP 3


Push the batteries in.



STEP 4

Close the box door.

Notice: Please don't keep the battery in the box when the power motion sofa is under daily use with power supply.



ITEM : 610523P

ASSEMBLY INSTRUCTIONS

