

and Leg(C) for front leg of chair. making clear Leg (B) for back leg of chair Do not attempt to assemble the chair before

the screws are tightened completely. Do not try to seat or use before confirm all




#### LA-A021NT-5PK



**ASSEMBLY INSTRUCTIONS** 

### **ASSEMBLY INSTRUCTION**






1.Firstly make clear leg (B) and leg (C)before trying to assemble; Leg(B) is shorter for back leg of chair ,Leg(C)is longer for front leg of chair,


Then align the leg(B) and leg (C) with seat (A) Secure.Bolt (D) and Washer(E) to connect Leg(B) and Seat (A); Secure Bolt (D) and Washer(E) to connect Leg(C) and Seat (A).

Some adjustments may be necessary to ensure the legs are aligned properly.






2.Pls secure screw all the bolts are tightened completely,four for each leg, totally 12pcs bolts, if you find the bolts can not be screwd tightenly ,pls return the chair.




# **ASSEMBLY INSTRUCTION**






1.Place Table Top(A) upper on the bottom (B) and secure with Bolts (H) and Washers(E) to connect table top (A) and bottom (B).

Some adjustments may be necessary to ensue two parts are aligned properly.




2. Put table glass (D) on the top (A) slightly. Now table can be used.




if you find the bolts can not be screwed tightened ,pls return the table.



## **ASSEMBLY INSTRUCTION**



1.Align the leg(B) with ottoman frame (A) via secure.Bolt (D) and Washer(E) Some adjustments may be necessary to ensure the legs are aligned properly.



2.Pls secure screw all the bolts are tightened completely, four for each leg, totally 12pcs bolts, if you find the bolts can not be screwd tightenly ,pls return the chair.



LEISURE AMERICA 03

# Need some help?

GIVE US A CALL: 1-888-980-5122 MON - FRI 8:30AM - 5:30PM (PT)



Outdoor furniture naturally weathers and shows color variation over time. We recommend the following care for the best results:

- Wipe with a soft cloth.
- Wash with mild soap and water as needed; do not use abrasive cleaners.
- Cover furniture with an outdoor cover (not included) when not in use.
- Store in a dry, covered area during inclement weather or winter season.



After assembly is completed, save these instructions and any included tools for future maintenance or re-assembly.