




ITEM NO: I358-360WD-WBK/WGY/WWT Writing Desk

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.



TOOLS REQUIRED (NOT PROVIDED)

PHILLIPS SCREWDRIVER


HARDWARE LIST:

No.	Description	Sketch	Quantity
A	Bolt Ø1/4" x 2"		10 PCS
B	Allen Wrench		1 PC

COMPONENTS LIST:

No.	Description	Sketch	Quantity
1	Desk Top		1 PC
2	Left Leg Assembly		1 PC
3	Right Leg Assembly		1 PC
4	Back Stretcher		1 PC

FUNCTIONALITY INSTRUCTION



Flip down keyboard tray

BEFORE USING THIS PRODUCT PLEASE READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS. Save these instructions for future reference.


FOR INDOOR USE ONLY



ITEM NO: I358-360WD-WBK/WGY/WWT Writing Desk

STEP 1: Put the desk top face down on a soft surface. And pull out the left & right drawers.

STEP 2: Attach right and left leg assemblies to the desk top using 8 bolts (A). Do not tighten completely.



STEP 3: Attach the back stretcher using 2 bolts (A). Then use the Allen wrench to tighten all bolts. Push back the left & right drawer boxes, and return the desk to the upright position.

