






ASSEMBLY INSTRUCTION

Model: U1830- CHAISE W/USB
U1830- LOVESEAT W/USB + DDT
U1830- ARMS







Description: REVERSIBLE SECTIONAL PULL OUT SOFA BED WITH ARM.

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
A	Chaise		1 PC
B	Left Arm		1 PC
C	Left Back		1 PC
D	Left Back Cushion		1 PC
E	Lovseat		1 PC


PARTS LIST:

NO.	DESCRIPTION	SKETCH	Q'TY
F	Right Arm		1 PC
G	Right Backrest		1 PC
H	Right Back		1 PC
I	Right Back Cushion		1 PCS
J	Plastic Feet		4 PCS
K	Screw		8 PCS


Step 1: Take out parts from BOX 2 OF 3



Step 2: Take out parts from BOX 1 OF 3



Step 3: Take out parts from BOX 3 OF 3



ASSEMBLY INSTRUCTION


Model: U1830- CHAISE W/USB
U1830- LOVESEAT W/USB + DDT
U1830- ARMS

Description: REVERSIBLE SECTIONAL PULL OUT SOFA BED WITH ARM.

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Step 4: Important:

1. Attach Plastic Feet (J) to the Cha (A) by the Screw (K).
2. Attach Left Arm (B) to the Left Seat (A).



Step 5: Important:

1. Attach the Left Back (C) to the Left Seat (A).
2. Attach Back Cushion (D) to the Left Seat (A).



ASSEMBLY INSTRUCTION

Model: U1830- CHAISE W/USB
U1830- LOVESEAT W/USB + DDT
U1830- ARMS


Description: REVERSIBLE SECTIONAL PULL OUT SOFA BED WITH ARM.

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Step 6:


Important:

1. Attach Right Arm (B) to the Right Seat (E).
2. Attach the Right Backrest (G) and Right Back (H) to the Right Seat (E).



Step 7:

Important: Attach Back Cushion (I) to the Right Seat (E).



ASSEMBLY INSTRUCTION


Model: U1830- CHAISE W/USB
U1830- LOVESEAT W/USB + DDT
U1830- ARMS

Description: REVERSIBLE SECTIONAL PULL OUT SOFA BED WITH ARM.

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment


Step 8:

Important: Connect the Left Chaise and Right Loveseat.



Step 9:

Assembly is completed.



ASSEMBLY INSTRUCTION


Model: U1830- CHAISE W/USB
U1830- LOVESEAT W/USB + DDT
U1830- ARMS

Description: REVERSIBLE SECTIONAL PULL OUT SOFA BED WITH ARM.

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment

Step 10:

Important: Connect the Left Loveseat and Right Chaise.



Step 11:

Assembly is completed.

