

MVEL2034X

2.0 cu. ft. Wi-Fi Enabled Over-the-Range Microwave Oven with EasyClean®

2.0 cu. ft Capacity

EasyClean®

WideView™ Window

LG ThinQ® with ThinQ Care

SmoothTouch™

Scan to Cook



AVAILABLE COLORS



PRINTPROOF™ STAINLESS STEEL

ThinQ Care

Proactive Smart Alerts to Keep Your Appliances Running Smoothly

- Preventative Alerts help you stay a step ahead of potential issues to find proactive solutions before problems arise.
- Avoid preventable repairs and service calls with real-time diagnostics for a hassle-free experience.
- Integrated within LG's ThinQ app—a smart home hub for managing your smart devices and appliances.

SUMMARY

Type Over-the-Range Microwave

CONVENIENCE FEATURES

Wi-Fi Connect (works with ThinQ®)

ThinQ UP

ExtendaVentTM 2.0

Racks

Turntable Diameter (inches)

Clock

Kitchen Timer

Completion Beeper

Turntable On/Off

Add 30 Second

Included Accessories

LIGHTING

Lighting (Exterior)

Lighting (Interior)

SAFETY FEATURES

Child Lock (Control Lock)

VENTING SYSTEM

Filtration

Exhaust Grease Filter

Power Levels

Vent Grille Type

Vent Air Flow (CFM)

MATERIALS/FINISHES

All Available Colors

PrintProof™ Finish

Interior Color

Handle Type

ThinQ® SMART FEATURES

ThinQ® (Wi-Fi Enabled)

ThinQ Up

Voice Control

Smart Recipe (3rd Party Recipe App)

SmartDiagnosis™

NFC Tag On

POWER/ RATINGS

Volts

Amps/ Watts

DIMENSIONS/ CLEARANCES/ WEIGHT

Cavity (WxHxD)

Exterior (WxHxD)

Net Weight (lbs)

Shipping Weight (lbs)

Shipping Dimensions (WxHxD)

LIMITED WARRANTY

Parts & Labor

Magnetron


UPC CODE

MVEL2034X

048231349277

MVEL2034X



PRODUCT OVERVIEW



- ① Vent Grille
- ② Glass Turntable
- ③ Location of Model Number
- ④ Cooking Guide

- ⑤ Grease Filter
- ⑥ Cooktop Light
- ⑦ Window with Metal Shield
- ⑧ Safety Door Lock System
- ⑨ Control Panel

DIMENSION



DIMENSIONS

Cavity (WxHxD)	21 15/16" x 11 3/16" x 14 9/16"
Exterior (WxHxD)	29 7/8" x 16 7/16" x 15 7/8"
Net Weight (lbs)	53.9
Shipping Weight (lbs)	64.2
Shipping Dimensions (WxHxD)	32 3/4 x 20 3/8 x 18 3/16

WARNING


Do not operate the oven when it is empty or without the glass tray. It is best to leave a glass of water in the oven when not in use. The water will safely absorb all microwave energy, if the oven is accidentally started.

CAUTION

- To avoid risk of personal injury or property damage, do not use stoneware, metal cookware, or metal rimmed cookware in the oven.
- Keep aluminum foil at least 1 inch from the oven walls and other pieces of foil. Foil can cause arcing if it gets too close to the oven walls during cooking.

ACCESSORIES

Accessories will vary depending on the model purchased.



1 Glass Tray



2 Rotating Ring